
SONY.

REMOTE CONTROL PANEL

RCP-3720 RCP-3721



OPERATION AND MAINTENANCE MANUAL 1st Edition (Revised 6)
Serial No. 10001 and Higher

For the customers in the USA

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

The shielded interface cable recommended in this manual must be used with this equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

For the customers in Canada

This apparatus complies with the Class A limits for radio noise emissions set out in Radio Interference Regulations.

Pour les utilisateurs au Canada

Cet appareil est conforme aux normes Classe A pour bruits radioélectriques, spécifiés dans le Règlement sur le brouillage radioélectrique. このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。 従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

目次

TABLE OF CONTENS

| 1. 取り扱い操作 | 2. 設置 |
|--|--|
| 1-1. 概要1-1 (J) | 2-1. 開梱と再梱包2-1 (J |
| 1-2. 各部の名称と働き1-3 (J) | 2-2. 標準付属品2-2 (J |
| 1-2-1. 電源および信号切り換えブロック 1-4 (J) | 2-3. 適合コネクター/ケーブル 2-3 (J |
| 1-2-2. タリーブロック 1-5 (J) | 2-3-1. コネクターの入出力信号 2-3 (J |
| 1-2-3. オートセットアップブロック 1-6 (J) | 2-3-2. 接続コネクター2-4 (J |
| 1-2-4. シーンファイルブロック 1-7 (J) | 2-4. 設置使用環境 |
| 1-2-5. フィルターおよびマスターゲイン | 2-5. 設置スペース 2-6 (J |
| 切り換えブロック1-8 (J) | 2-5-1. 設置条件 |
| 1-2-6. シャッタースピード切り換え | 2-5-2. 外形寸法 |
| ブロック 1-10(J) | 2-5-3. コンソールへの取り付け方法 2-8 (J |
| 1-2-7. LOCKボタン1-11(J) | 2-6. 基板内スイッチのセッティング 2-9 (J) |
| 1-2-8. ニー/ガンマ/ディテイル | 2-7. システム接続2-10(J) |
| 調整ブロック1-12(J) | |
| 1-2-9. ペインティングプロック 1-13(J) | 2. INSTALLATION |
| 1-2-10. アイリスマスタープラック | |
| 調整ブロック 1-14(J) | 2.1 Packing and Unnaching 2.1 (F) |
| 1-2-11. コネクターパネル1-18(J) | 2-1. Packing and Unpacking 2-1 (E) 2-2. Supplied Accessories 2-2 (E) |
| 1-3. 接続 | 2-3. Connectors and Cables |
| 1-3-1. CCUの接続1-19(J) | 2-3-1. Connector Input/Output Signals 2-3 (E) |
| 1-3-2. プレビューコネクター1-20(J) | 2-3-2. Connectors 2-4 (E) |
| 1-4. 操作1-21(J) | 2-4. Operating Environment |
| 1-4-1. ホワイトバランスとブラックバランスの | 2-5. Installation Space |
| 自動調整1-22(J) | 2-5-2. Outside Dimensions |
| 1-4-2. 絞りの調整1-23(J) | 2-5-3. Installation to Console 2-8 (E) |
| 1-4-3. シーンファイル操作1-24(J) | 2-6. Function of Switch ON PC Board 2-9 (E) |
| 1-5. 仕様 | 2-7. System Configuration 2-10(E) |
| - J. [2](0) | 0 # 6775744 8-15 |
| 1. OPERATION | 3. サービスインフォメーション |
| | 2.1 计更初日本存在计 |
| 1-1. Overview 1-1 (E) | 3-1. 主要部品の交換方法3-1 (J) |
| 1-2. Locations and Functions of Parts and | 3-1-1. 外装の外し方 |
| Controls | 3-1-2. ジョイスティックボリュームの交換方法 |
| 1-2-1. Power Supply and Signal Selector Block | (RCP-3720のみ) 3-2 (J) |
| 1-2-2. Tally Block | 3-1-3. コントロールパネルの外し方 3-3 (J) |
| 1-2-3. Auto Setup Block | 3-2. サービス上の注意事項 3-4 (J) |
| 1-2-4. Scene File Block 1-7 (E) | 3-2-1. PROM IC |
| 1-2-5. Filter and Master Gain Selector Block 1-8 (E) | 3-2-2. 補修用部品の注意事項 3-4 (J) |
| 1-2-6. Shutter Speed Selector Block | 3-2-3. 治工具 |
| 1-2-7. LOCK Button | 3-2-4. チップ部品交換時の注意事項 3-5 (J) |
| Block1-12 (E) | 3. SERVICE INFORMATION |
| 1-2-9. Painting Block 1-13 (E) | 3. SERVICE INFORMATION |
| 1-2-10. Iris and Master Black Adjustment Block 1-14(E) | 3-1. Replacement of Main Parts 3-1 (E) |
| 1-2-11. Connector Panel | 3-1-1. Cabinet Removal 3-1 (E) |
| 1-3. Connections | 3-1-2. Replacement of Joystick Control |
| 1-3-2. PREVIEW Connector | (only for RCP-3720) 3-2 (E) |
| 1-4. Operation | 3-1-3. Removal of Control Panels |
| 1-4-1. Automatic Adjustment of White and | 3-2. Note on Maintenance Services |
| Black Balance | 3-2-2. Note on Replacement Parts |
| 1-4-2. Iris Adjustment | 3-2-3. Fixture |
| 1-4-5. Scene File Operation | 3-2-4. Replacement of Chip Parts 3-5 (E) |
| | |

A. DIAGRAMS

В.

C.

| Doard Layout | 1 |
|---|----|
| Block Diagram A- | 4 |
| Frame (1/2) | |
| MPU-53 A- | 9 |
| Frame (2/2) | |
| DSP-27, DSP-28, IR-12, LED-98, LED-109, | |
| SW-371 A- | 14 |
| | |
| SEMICONDUCTOR PIN ASSIGNMENT | S |
| | |
| SPARE PARTS | |
| | |
| Parts Information C- | 1 |
| Exploded View C- | 2 |

第1章 取り扱い操作

1-1. 概要

リモートコントロールパネルRCP-3720/3721は、3板式CCDカラービデオカメラBVP-370/270の調整機能を、カメラコントロールユニットCCU-370を介してリモートコントロールするためのコントロールパネルです。本機は、専用のケーブルでCCU-370に接続することにより、CCU-370から最大200m離して使用することができます。

RCP-3720とRCP-3721は、アイリス/マスターブラック調整部の形状が異なるだけで、 機能的にはまったく同一です。アイリス/マスターブラック調整部は、RCP-3720ではジョイスティックタイプ、RCP-3721ではつまみになっています。

本機の主な特長は次の通りです。

カメラの基本的オペレーションに適した操作性

本機は、カメラの基本的オペレーションに必要かつ十分なコントロール機能を備えています。操作ボタン、調整つまみ等は、機能別に、使う頻度を考慮してパネル上に配置し、さらに操作手順が自照式ボタンの点滅や点灯の状態でわかるように工夫されています。 また、誤操作した場合にカメラの動作やセットアップに重大な影響を及ぼすボタンの周囲にはガードを付けるなど、さまざまな機能を簡単に、そして間違いなく操作できるようになっています。

シーンファイル機能

撮影シーンに合わせて、ペインティング等の操作により調整したデータを、シーンファイルとして最大5つまで保管しておき、必要に応じてデータを呼び出して、シーンに合った撮影条件を簡単に再現することができます。

カメラのシャッタースピードをコントロール可能

CCDカメラの電子シャッタースピードを、ボタン操作で6段階に切り換えることができます。

デジタル回線による接続

カメラコントロールユニットと本機との間は、デジタル回線による信号の受け渡しを行います。1本の接続ケーブル (CCA-2) ですべての信号の授受を確実に行うことができます。

MSUとの同時コントロールが可能

本機とマスターセットアップユニットMSU-350との同時コントロールが可能です。同時コントロールのモードはパラレル(並行)、スプリット(分担)の2種類があります。パラレルモードのときは、本機側はすべての機能を使えますが、マスターセットアップユニット側では、絞りとマスターブラックの調整機能が使えなくなります。一方、スプリットモードのときは、本機側では絞りとマスターブラックの調整のみが可能になります(スプリットモードのときも、マスターセットアップユニット側では絞り/マスターブラック調整機能を使えません)。

ベータカムカメラのコントロールも可能


本機をカメラコントロールユニットCCU-350/355に接続すれば、カメラアダプターを取り付けたベータカムシリーズカメラ (BVP-7/50/70/7000HSなど) もコントロールできます。

19インチのラックに4台取り付け可能


本機は、19インチのEIA標準ラックに4台並べて取り付けることができます。(高さは7ユニット)

本機は、CCDカラービデオカメラ専用のリモートコントロールパネルです。 撮像管式カメラのコントロールはできません。

1-2. 各部の名称と働き



1-2-1. 電源および信号切り換えブロック



● PANEL ACTIVE (パネルアクティブ) ボタン

本機に接続したカメラシステムを本機でコントロールするときに、押して点灯させます。 このボタンが消灯しているときは、本機からカメラシステムをコントロールすることは できません。ただし、カメラの現在の状態を表示する機能は、PANEL ACTIVEボタンの 消灯時も働きます。

2 PARA (同時コントロール) ボタン

点灯または点滅することによって、本機がマスターセットアップユニットとの同時コントロール状態にあることを示します。パラレルモードのとき点灯し、スプリットモードのとき点滅します。

パラレルモード (点灯) は、ボタンを押して消灯させれば解除できますが、スプリット モード (点滅) は解除できません。(パラレルモード時は、本機のすべての機能を使えま すが、スプリットモード時は、本機側では絞りとマスターブラックの調整のみ可能です。)

❸ CAM PW(カメラヘッド電源)ボタン

押して点灯させると、カメラヘッドに電源が供給されます。 もう一度押して消灯させると、カメラヘッドに電源が供給されなくなります。

4 TEST (テスト) ボタン


押して点灯させると、カメラのテスト信号発生器が作動して、ビデオ回路チェック用の テスト信号 (のこぎり波形) が出力されます。

もう一度押して消灯させると、テスト信号は出力されなくなります。

⑤ BARS (カラーバー) ボタン

押して点灯させると、カラーバー信号が出力されます。 もう一度押して消灯させると、カラーバー信号は出力されなくなります。

1-2-2. タリーブロック



6 カメラ番号表示

本機でコントロールするカメラと同じ番号のナンバープレート (付属) を、ここに取り付けます。

7 CALL (コール) ボタン兼レッドタリーランプ


押しているあいだ、カメラヘッドおよびカメラコントロールユニットのレッドタリーランプが点灯します。

また、カメラにレッドタリー信号が入力されると点灯します。

③ グリーンタリーランプ

カメラにグリーンタリー信号が入力されると点灯します。

1-2-3. オートセットアップブロック



② LEVEL (レベル) 自動調整ボタン

押して点灯させると、ガンマバランス、ニーポイント、マスターブラックレベルが自動 的に調整されます。調整が完了するとボタンは消灯します。

自動調整時にエラーが発生した場合は、ボタンが点滅します。点滅を止めるには、本機 のいずれかのボタンを押します。

WHITE(ホワイトバランス)自動調整ボタン

押して点灯させると、ホワイトバランスが自動的に調整されます。調整が完了するとボタンは消灯します。


自動調整時にエラーが発生した場合は、ボタンが点滅します。点滅を止めるには、本機 のいずれかのボタンを押します。

働 BLACK (ブラックバランス) 自動調整ボタン

押して点灯させると、ブラックバランスとブラックセットが自動的に調整されます。調整が完了するとボタンは消灯します。

自動調整時にエラーが発生した場合は、ボタンが点滅します。点滅を止めるには、本機 のいずれかのボタンを押します。

1-2-4. シーンファイルブロック



⑫ STORE (シーンファイル登録) ボタン

押して点滅させると、引き続きファイル番号選択ボタン®で選択したファイルに、カメラの現在の調整値を登録することができます。ファイルに調整値が登録されると、このボタンは消灯します。

登録を中止したいときは、ファイル番号選択ボタンを押す前に、もう一度このボタンを押して点滅を止めます。

13 ファイル番号選択ボタン


STOREボタン®の点滅時:

これらのボタンの1つを押して点灯させると、その番号のファイルに現在の調整値が保管されます。

STOREボタン®の消灯時:

- ・これらのボタンの1つを押して点灯させると、その番号のファイルが呼び出されます。
- ・ 点灯しているボタンを押して消灯させると、その番号のファイルが呼び出される前の 状態に戻ります。

1-2-5. フィルターおよびマスターゲイン切り換えブロック




M ND FILTER (NDフィルター) 表示部

現在選択されているNDフィルターを示します。BVP-370/270のカメラシステムをコントロールするときは、表示される番号とNDフィルターは次のように対応しています。

- 1: 素通し
- 2: 1/4 ND
- 3: 1/8 ND
- 4: 1/16 ND

(I) ND FILTER (NDフィルター) 切り換えボタン

一度押すと点灯します。点灯中は、押すたびにNDフィルターが次の順序で切り換わります (押し続けると、順次切り換わります)。



(f) CC FILTER (色温度変換フィルター) 表示部

現在選択されている色温度変換フィルターを示します。BVP-370/270のカメラシステムをコントロールするときは、表示される記号と色温度変換フィルターは次のように対応しています。

- A: 特殊フィルター*
- B: 3200K
- C: 4300K
- D: 6300K
- * カメラヘッドBVP-370/270の工場出荷時は、クロスフィルターが装着されています。ほかのフィルターをご希望の場合は、ソニーの担当者にご相談ください。

⑦ CC FILTER (色温度変換フィルター) 切り換えボタン

一度押すと点灯します。点灯中は、押すたびに色温度変換フィルターが次の順序で切り 換わります (押し続けると、順次切り換わります)。

$$\blacktriangle: \rightarrow A \rightarrow B \rightarrow C \rightarrow D -$$

なお、動と動のボタンは、いずれか1つを押せばすべてが点灯し、NDフィルター、色温度 変換フィルターともに切り換え可能となります。

(B) MASTER GAIN (マスターゲイン) 切り換えボタン


被写体の照度に応じて映像利得を切り換えたいとき、希望のボタンを押して点灯させます。

- 0: 0dB
- 9: 9dB
- 18: 18dB

19 予備ボタン

このボタンには、いかなる機能も割り当てられていません。

1-2-6. シャッタースピード切り換えブロック



② SHUTTER SPEED (シャッタースピード) 表示部

現在選択されているシャッタースピードを表示します。

100: 1/100秒

125: 1/125秒

250: 1/250秒

500: 1/500秒

1000: 1/1000秒

2000: 1/2000秒

② SHUTTER ON (シャッター オン) ボタン

押して点灯させると、現在選択されている(すなわちSHUTTER SPEED表示部のに表示されている)シャッタースピードで、カメラの電子シャッターが動作します。

もう一度押して消灯させると、シャッターは動作しなくなります。

このボタンの点灯時は、SHUTTER SPEED切り換えボタン❷で、実際にカメラのシャッタースピードを切り換えることができます。

② SHUTTER SPEED (シャッタースピード) 切り換えボタン

SHUTTER ONボタン●を点灯させると、これらのボタンも点灯し、もう一度SHUTTER ONボタンを押して消灯させると、これらのボタンも消灯します。


これらのボタンの点灯時は、押すたびにシャッタースピード (単位: 秒) が次の順序で 切り換わります (押し続けると、順次切り換わります)。

▶ : \rightarrow 1/100 \rightarrow 1/125 \rightarrow 1/250 \rightarrow 1/500 \rightarrow 1/1000 \rightarrow 1/2000 \rightarrow

◄: → 1/2000 → 1/1000 → 1/500 → 1/250 → 1/125 → 1/100 −

消灯時は、ボタンを押しても、本機側におけるシャッタースピードの選択が変わる (SHUTTER SPEED表示部●に表示される数値が変わる) だけで、カメラのシャッタースピードそのものは切り換わりません。


1-2-7. LOCKボタン



⚠ LOCK (ロック) ボタン

押して点灯させると、アイリス/マスターブラック調整ブロック以外のボタンや調整つまみが働かなくなります。もう一度押して消灯させると、ボタンやつまみが再び働くようになります。

1-2-8. ニー/ガンマ/ディテイル調整ブロック




AUTO KNEE (オートニー) ボタン

押して点灯させると、カメラヘッドのオートニー回路が作動します。 もう一度押して消灯させると、オートニー回路は作動しなくなります。

- ② KNEE ENB (ニー イネーブル) ボタンとKNEE (ニーポイント) 調整つまみ ボタンを押して点灯させると、下のつまみでニーポイントを調整できます。ボタン消灯 時は、つまみは働きません。
- ② GAMMA ENB (ガンマ イネーブル) ボタンとGAMMA (ガンマ) 調整つまみ ボタンを押して点灯させると、下のつまみでマスターガンマを調整できます。ボタン消 灯時は、つまみは働きません。
- ② DETAIL ENB (ディテイル イネーブル) ボタンと DETAIL (ディテイル) 調整つまみ ボタンを押して点灯させると、下のつまみでディテイルを調整できます。ボタン消灯時 は、つまみは働きません。

1-2-9. ペインティングブロック



② ABSOLUTE (絶対値モード) ボタン

押して点灯させると、WHITE調整つまみ●とBLACK調整つまみ●の働きが、相対値モードから絶対値モードに切り換わり、それぞれホワイトバランス、ブラックバランスが、つまみのインデックス(▲)が指す通りの値に調整されます。(絶対値モード、相対値モードについては、1-22 (J) ページの脚注を参照してください。)

② WHITE (ホワイトバランス) 調整つまみ

ホワイトバランス手動調整用のつまみで、左から順にR、G、B信号を調整します。オートホワイトバランス実行後のペインティング用に使うことができます。

つまみの中央にクリックがあります。

これらのつまみの調整モードは、ABSOLUTEボタン®の点灯時は絶対値モード、消灯時は相対値モードになります。(1-22 (J) ページの脚注参照)


3 BLACK (ブラックバランス) 調整つまみ


ブラックバランス手動調整用のつまみで、左から順にR、G、B信号を調整します。オートブラックバランス実行後のペインティング用に使うことができます。

つまみの中央にクリックがあります。

これらのつまみの調整モードは、ABSOLUTEボタン®の点灯時は絶対値モード、消灯時は相対値モードになります。(1-22 (J) ページの脚注参照)

1-2-10. アイリス/マスターブラック調整ブロック





6 RELATIVE (相対値モード) ボタン

押して点灯させると、RCP-3720の場合はIRIS調整レバー動とマスターブラック調整リング●、RCP-3721の場合はIRIS調整つまみ●とMASTER BLACK調整つまみ●の働きが、絶対値モードから相対値モードに切り換わります。(1-24 (J) ページ参照)

② EXTENDER (レンズエクステンダー) インジケーター (こはく色)
レンズエクステンダーを使用しているとき点灯します。

MASTER BLACK(マスターブラック)表示部

マスターブラックの調整値を、パーセントで表示します。

マスターブラック調整リングlacktriangle (RCP-3720) またはMASTER BLACK調整つまみlacktriangle (RCP-3721) が絶対値モードにあるとき (RELATIVEボタンlacktriangle 消灯時) は、リングまたはつまみの位置に対応した値を表示します。

リングまたはつまみが相対値モードにあるとき (RELATIVEボタン点灯時) にシーンファイルを呼び出すと、呼び出し時のリングまたはつまみの位置に関係なく、ファイルに保管されているマスターブラック値を表示します。

34 IRIS (アイリス) 表示部

絞りの設定値を f ナンバーで表示します。レンズを絞り切ると、「CL」と表示されます。

🚯 AUTO IRIS(自動レンズ絞り)ボタン

押して点灯させると、レンズの絞りが自動調整されます。入力光に応じて自動的に絞り が調整され、基準の明るさの映像が得られます。ボタン点灯時にIRIS調整レバー@ (RCP-3720) またはIRIS調整つまみ● (RCP-3721) を動かすと、自動調整の基準値を± 1Fの範囲で変えることができます(中央が標準値)。

もう一度押して消灯させると、IRIS調整レバーまたはIRIS調整つまみで絞りを手動調整することができます。

(f) IRIS COARSE (アイリス粗調整) つまみ

レンズの絞りを粗調整するためのつまみです。

(アイリス微調整感度) 調整ねじ

IRIS調整レバー® (RCP-3720) またはIRIS調整つまみ® (RCP-3721) で手動調整できる絞りの可変範囲を設定します。ドライバーで回して調整します。右へ回すと感度が上がり、絞り調整の可変範囲が狭くなります。

マスターブラック調整リング®を回すと一緒に回転し、マスターブラックのおおよその 調整値を示します。ただし、RELATIVEボタン®が点灯しているときは、このインジケー ターの位置とマスターブラック値との対応関係はなくなります。

AUTO IRISボタン●の消灯時に、このレバーを前後に動かして絞りを手動調整することができます。(調整範囲の中心はIRIS COARSEつまみ●で、幅はSENS調整ねじ●で調整することができます。)

AUTO IRISボタン点灯時は、このレバーで絞り自動調整の基準値を ± 1 Fの範囲で調整できます。

RELATIVEボタン●の点灯時は、このレバーは相対値モードで働きます。(1-24(J)ページ参照)

レバー (ノブ) を軸方向に押すと、プレビュー用キー信号がPREVIEWコネクター (「1-2-11」参照)から出力され、本機でコントロールしているカメラの映像信号がモニターに表示されます。

① マスターブラック調整リング (RCP-3720)

マスターブラック手動調整用のリングです。リングを回すとマスターブラックインジケーター

・おおよその調整値を示します。

RELATIVEボタン●の点灯時は、このリングは相対値モードで働きます。 (1-24 (J) ページ参照)

4 ジョイスティックトルク調整ねじ(RCP-3720)

IRIS調整レバー動を前後に動かすときのレバーの動きの固さを、ドライバーで調整します。右に回すとレバーの動きが固くなります。

(P) IRIS (アイリス) 調整つまみ (RCP-3721)

AUTO IRISボタン®の消灯時に、このつまみを回して絞りを微調整することができます。 (調整範囲の中心はIRIS COARSEつまみ®で、幅はSENS調整ねじ®で調整することが できます。)

AUTO IRISボタン点灯時は、このつまみで絞り自動調整の基準値を ± 1 Fの範囲で調整できます。

RELATIVEボタン●の点灯時は、このレバーは相対値モードで働きます。(1-24 (J) ページ参照)。


押して点灯させると、プレビュー用キー信号がPREVIEWコネクター (「1-2-11」参照)から出力され、本機でコントロールしているカメラの映像信号がモニターに表示されます。

MASTER BLACK(マスターブラック) 調整つまみ(RCP-3721)

マスターブラック手動調整用のつまみです。

RELATIVEボタン●の点灯時は、このつまみは相対値モードで働きます。 (1-24 (J) ページ参照)

1-2-11. コネクターパネル



① CCUコネクター (16ピン)

カメラコントロールユニットのRCPコネクター(16ピン)に接続します。本機への電源 供給およびコントロール信号の受け渡しが行われます。詳しくは「1-3-1. CCUの接続」 を参照してください。

2 PREVIEW (プレビュー) コネクター

RCP-3720の場合は、プレビューノブ入/切の信号を、外部のビデオスイッチャーなどに 出力します。


RCP-3721の場合は、PREVIEWボタンのオン/オフ信号の出力とボタン点灯用の電源の入力を、外部のビデオスイッチャーなどとの間で行います。

詳しくは「1-3-2. プレビューコネクター」を参照してください。

1-3. 接続

1-3-1. CCUの接続

カメラコントロールユニットと本機の接続には、別売りのカメラ接続ケーブルCCA-2-30 (長さ30m) を使用します。これ以外のケーブル (ただしCCA-2相当) をお使いになるときは、付属の16ピンコネクターを使って、下図のように配線してください (長さは200mを超えないようにしてください)。




1-3-2. プレビューコネクター

PREVIEWコネクターは下図のように配線されており、外部のビデオスイッチャーなどを コントロールできます。


RCP-3720

プレビューノブ用SWの最大電流は1mAです。



RCP-3721

PREVIEWボタン用の電源は5V、SWの最大電流は1mAです。



1-4. 操作

本機を使ってカメラシステムをコントロールするには、PANEL ACTIVEボタンを押して 点灯させます。

PANEL ACTIVEボタン、PARAボタンの状態と操作可能なブロックの関係は次の通りです。

| ボタンの状態 | | |
|--------------------------|------|-----------------------------------|
| PANEL ACTIVE | PARA | 操作可能なブロック |
| 点灯 点澜 | 点灯 | 全ブロック(PARAボタンも含む)* |
| | 点滅 | アイリス/マスターブラック調整ブロックのみ |
| | 消灯 | 全ブロック(PARAボタンを除く)* |
| 点灯 点滅 PANEL ACT 消灯 | | |
| | 点滅 | PANEL ACTIVE、LOCK、RELATIVEボタンのみ** |
| | | |


^{*} LOCKボタン点灯時は、アイリス/マスターブラック調整ブロックとLOCKボタン以外は働きません。LOCKボタンを押して消灯させると、他のブロックも操作可能になります。

^{**}LOCKボタン点灯時は、PANEL ACTIVEボタンは働きません。 LOCKボタンを押して消灯させると、PANEL ACTIVEボタンも 働くようになります。

1-4-1 ホワイトバランスとブラックバランスの自動調整

ホワイトバランスとブラックバランスの自動調整は、下記の手順で行います。

- 1 AUTO IRISボタンを押して点灯させ、絞りを自動調整モードにします。
- 2 WHITEとBLACKの調整つまみをすべて中央位置にします。*
- **3** 被写体を照らす光源に合わせ、CC FILTER切り換えボタンで色温度変換フィルターを選びます。
- 4 必要に応じて、ND FILTER切り換えボタンでNDフィルターを切り換えます。
- **5** ホワイトパターンを写します。白いもの(白い紙、白い壁など)で代用することもできます。



- **6** WHITE自動調整ボタンを押して点灯させ、ホワイトバランスを調整します。 調整が完了するとボタンが消灯します。**
- **7** BLACK自動調整ボタンを押して点灯させ、ブラックバランスを調整します。 調整が完了するとボタンが消灯します。**

なお、自動調整後も、ABSOLUTEボタンを押して点灯させれば、つまみの働きは絶対値モードに変わり、中央位置が調整範囲の中央値に対応するようになります。

^{*} 手順2を省略しても、ホワイト/ブラックバランスは自動的に調整されます。ただし自動調整後は、これらのつまみの働きは相対値モードになり、つまみの位置と調整値との絶対的な対応関係がなくなります。すなわち、中央位置は必ずしも調整範囲の中央値に対応せず、自動調整時の位置が、その後のペインティングなど手動調整の基準位置になります。したがって、中央位置を自動調整後の基準位置にしたいときは、手順2を実行して

^{**}調整中にエラーが発生した場合は、ボタンが点滅して知らせま す。点滅を止めるには、本機のいずれかのボタンを押します。

1-4-2. 絞りの調整

レンズの絞りは、AUTO IRISボタンを押して点灯させておくと自動的に調整されますが、必要に応じて手動で調整することもできます。

自動調整

- **1** IRIS調整レバー (RCP-3720) またはIRIS調整つまみ (RCP-3721) を中央の位置に します。
- **2** AUTO IRISボタンを押して点灯させます。 絞りは入力光に応じて自動的に最適値に調整されます。
 - ・AUTO IRISボタンが点灯し、絞りが自動調整になっているとき、IRIS調整レバーまたはIRIS調整つまみを動かすと、自動調整の基準値を±1Fの範囲で変えることができます。

手動調整

調整範囲の設定

- 1 AUTO IRISボタンが点灯しているときは、ボタンを押して消灯させます。
- **2** IRIS調整レバー (RCP-3720) またはIRIS調整つまみ (RCP-3721) を中央の位置に します。
- **3** IRIS COARSEつまみで、IRIS調整レバーまたはIRIS調整つまみによる調整範囲の中心値を設定します。
- 4 RCP-3720の場合はIRIS調整レバーを前後いっぱいに動かし、RCP-3721の場合は IRIS調整つまみを左右いっぱいに回して、絞りの調整範囲を確認します。 調整範囲を変更したいときは、ドライバーでSENS調整ねじを回して調整します(右へ回すと感度が上がり、調整範囲が狭くなります)。

調整

IRIS調整レバーまたはIRIS調整つまみを動かして、最適な映像が得られるように絞りを調整します。

IRIS調整レバー (RCP-3720)、IRIS調整つまみ (RCP-3721) の働きは、RELATIVEボタン 消灯時は絶対値モード、点灯時は相対値モードになります。マスターブラック調整リング (RCP-3720)、MASTER BLACK調整つまみ (RCP-3721) も同様です。

絶対値モードでは、レバーやつまみの位置が調整項目の値と絶対的に対応しており、中 央位置がそのまま調整範囲の中央値に対応します。

一方、相対値モードでは、レバーやつまみの位置と調整値との絶対的な対応関係がなくなります。すなわち、中央位置は必ずしも調整範囲の中央値に対応せず、絶対値モードから相対値モードに切り換わるときの位置が、その後の相対値調整の基準位置になります。

AUTO IRISボタンを押して消灯させ、絞りを自動調整から手動調整に切り換えるときに、RELATIVEボタンが消灯していると(絶対値モード)、絞りは瞬間的に、そのときのIRIS調整レバー (RCP-3720)、IRIS調整つまみ (RCP-3721) の位置に対応する値に変わります。したがって、切り換え時のレバー (つまみ) の位置によっては、映像の明るさが大きく変化することがあります。

AUTO IRISボタン点灯中にRELATIVEボタンを押して点灯させておくと(相対値モード)、手動調整に切り換えても直前の自動調整値が保持されるため、上記の現象を避けることができます。

1-4-3. シーンファイル操作

撮影シーンに合わせた調整値などのデータを、シーンファイルとして最大5種類(ファイル1~5) カメラヘッドに保管しておき、必要に応じて任意のファイルを呼び出し、使用することができます。

シーンファイルに保管できるデータは次の通りです。

NDフィルターの設定

色温度変換フィルターの設定

マスターゲイン設定値

シャッタースピード設定値

オートニー回路のオン/オフ状態

ニーポイント設定値

ガンマ設定値

ディテイル設定値

ホワイトバランス設定値

ブラックバランス設定値

オートアイリス回路のオン/オフ状態

マスターブラック設定値

保管の手順

- 1 撮影シーンに合わせて、必要な項目を調整します。
- 2 STOREボタンを押して点滅させます。
- **3** 調整値を保管しておくシーンファイルの番号を、ファイル番号選択ボタンで指定します。

押したボタンが点灯し、指定したファイルに調整値が登録されます。登録が完了すると、点滅していたSTOREボタンは消灯しますが、ファイル番号選択ボタンは点灯し続けます。

・すでにデータが登録されているファイルを指定すると、前のデータが消えて新し いデータが登録されます。

シーンファイルの呼び出し

- **1** WHITE調整つまみとBLACK調整つまみをすべて中央位置にします。*
- **2** 使用したいファイルの番号を、ファイル番号選択ボタンで指定します。 押したボタンが点灯し、指定したファイルのデータが呼び出されます。
 - ・点灯しているファイル選択番号を押して消灯させると、カメラシステムはファイルが呼び出される前の状態に戻ります。

^{*} 手順1を実行しなくてもファイルは呼び出せますが、呼び出し後これらのつまみの調整モードは相対値モードになるため、中央位置を調整の基準位置にしたいときは手順1を実行してくたさい。(1-22(J)ページの脚注も併せて参照してください。)

1-5. 仕様

入出力コネクター CCUコネクター (16ピン)

PREVIEWコネクター (6ピン)

電源 DC 30V

消費電力 4W

最大ケーブル長 200m (CCA-2ケーブルまたは同等品使用の場合)

重き RCP-3720: 1,7kg

RCP-3721: 1.4kg

外形寸法(幅/高さ/奥行き) RCP-3720: 102×354×127mm

RCP-3721: 102×354×84mm

(最大突起部を含む)

付属品 16ピンコネクター (2)

6ピンコネクター (1)

ナンバープレート (1式)

オペレーション アンド メンテナンスマニュアル (1)

別売りアクセサリー カメラ接続ケーブル (CCA-2-30)

本機の仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

Section 1. Operation

1-1. Overview

The RCP-3720/3721 remote control panel is designed for remote control of those functions of the BVP-370/370P/270/270P 3-chip CCD color video camera which are used most frequently in basic operation. The panel is to be connected to the CCU-370/370P camera control unit by a special cable with a length of up to 200 m, and control the camera functions via the camera control unit.

The RCP-3720 and RCP-3721 are completely identical in their functions. In terms of operation they differ only with respect to the type of knob for iris and master black adjustments: while the RCP-3720 uses a joystick type control for these adjustments, the RCP-3721 uses rotary knobs. The principal features of the RCP-3720/3721 are as follows:

Optimal control parts arrangement for basic camera operation

This remote control panel is provided with all necessary control functions for basic operation of the BVP-370/370P/270P video camera. The controls such as buttons and knobs are arranged on the panel according to function with consideration given to the frequencies at which they are used. The buttons blink or light up in such a way that the operator is smoothly guided to follow the correct operating procedure. In addition, those buttons which, if pressed by mistake, might seriously affect the camera operation or setup are each protected with a guard frame. This and other features ensure easy and error-free operation of many different functions.

Scene file function

Camera adjustment and control data such as painting data for a particular scene can be stored in the camera head in the form of a scene file. The stored data can easily be recalled at any time to automatically adjust the video camera to the shooting condition for that particular scene. This panel enables up to five scene files to be created and handled.

Shutter speed control

The electronic shutter speed of the CCD camera can be varied through a range of six speeds.

Signal transmission via digital line

Between this remote control panel and the camera control unit, signals are digitally transmitted via a single connection cable (CCA-2-30), ensuring reliable signal transmission.

Concurrently operable with a master setup unit

This panel can be operated concurrently with an MSU-350 master setup unit. Concurrent control of the camera system by this panel and the master setup unit can be possible in two modes: a parallel, and a split mode. In the parallel mode, all functions of this panel are effective while in the split mode it is only iris and master black adjustment that can be performed from this panel. (These two items cannot be adjusted from the master setup unit whether in the parallel or split mode.)

Betacam camera control


When connected to the CCU-350/350P/355/355P camera control unit, the panel can be used to control a Betacam-series camera (such as BVP-7/7P/50/50P/70/70P/7000HS/7000HSP) attached with a camera adaptor.

Four units mountable on 19-inch rack


Up to four units of this remote control panel can be mounted on a 19-inch EIA standard rack (seven rack units high).

This remote control panel is designed for exclusive use with CCD color video cameras. It cannot be used to control video cameras with tube type pickup device.

1-2. Locations and Functions of Parts and Controls



1.2.1. Power Supply and Signal Selector Block



1 PANEL ACTIVE button

When this button is pressed, it lights and makes it possible to control the camera system from this remote control panel. When the button is unlit, the camera system cannot be controlled from the panel. However, even with the button unlit, the function of the panel to indicate the current condition of the camera system is effective.

2 PARA (parallel mode) button

When lit, this button indicates that this panel and a master setup unit connected to the same camera system are in the parallel control mode (namely, that you can use all functions of this panel).

When blinking, it indicates that the two units are in the split control mode (namely, that it is only iris and master black adjustment which can be performed from this panel).

When the PARA button is lit, you can make the panel exit from the parallel control mode by pressing the button to turn it off. However, when the button is blinking, you cannot make the panel exit from the split control mode: pressing the button will result in no change.

3 CAM PW (camera head power) button

When this button is pressed, it lights and power is supplied to the camera head. To cut off the camera head power supply, press the button again to make it go out.


4 TEST button

When this button is pressed, it lights and causes the test signal generator in the camera head to output the video circuit testing signal of sawtooth waveform. To turn off the test signal generator, press this button again to make it go out.

6 BARS button

When this button is pressed, it lights and causes the color bar signal to be output. To cut off the color bar signal, press this button again to make it go out.

1-2-2. Tally Block



6 Camera number indicator

Attach the number plate (supplied) corresponding to the number of the camera which is to be controlled from this panel.


7 CALL button/red tally lamp

While the button is pressed, a call signal is transmitted to the camera head and the camera control unit, keeping their red tally lamps lit. The button also works as a red tally lamp: it lights when a red tally signal is input to the camera.

(3) Green tally lamp

This lamp lights when a green tally signal is input to the camera.

1-2-3. Auto Setup Block



9 LEVEL button

When this button is pressed, it lights and gamma balance, knee point and master black level are automatically adjusted. It goes out upon completion of the automatic adjustment.

If an error occurs during the automatic adjustment, this button starts blinking. To stop it from blinking, press any button on the panel.

WHITE button


When this button is pressed, it lights and white balance is automatically adjusted. It goes out upon completion of the automatic adjustment.

If an error occurs during the automatic adjustment, this button starts blinking. To stop it from blinking, press any button on the panel.

BLACK button

When this button is pressed, it lights and black balance and black set are automatically adjusted. It goes out upon completion of the automatic adjustment. If an error occurs during the automatic adjustment, this button starts blinking. To stop it from blinking, press any button on the panel.

1-2-4. Scene File Block



STORE button

When this button is pressed, it starts blinking and makes it possible to store the current camera adjustment data in a scene file to be selected by pressing one of the file number select buttons . The STORE button stops blinking on completion of data storing.

To cancel data storing, press the button again to stop it from blinking before pressing a file number select button.

(B) File number select buttons

When the STORE button ® is blinking:

Pressing one of these buttons causes it to light and the current camera adjustment data to be stored in the scene file of the corresponding number.

When the STORE button is unlit:

- Pressing one of these buttons causes it to light, the stored camera adjustment data
 to be recalled from the scene file of the corresponding number and the camera to
 be automatically adjusted according to the recalled scene file data.
- Pressing the lit one of these buttons causes it to go out and the camera system to return to the status it was in before the adjustment data was recalled from the scene file of the corresponding number.

1 ND FILTER display window

This display window indicates the current ND filter selection. When this panel is used to control the BVP-370/370P/270P camera system, the numbers which are displayed here and the ND filter selections correspond as follows:

- 1: Clear
- 2: 1/4 ND
- 3: 1/8 ND
- 4: 1/16 ND

(B) ND FILTER select buttons

Once either button is pressed, both buttons (and also the CC FILTER select buttons

(B) light up.

Every time one or the other ND FILTER select button is pressed while lit, the ND filter selection changes as shown below. (If the button is kept pressed, the filter selection

continues to change.)

▼: → 4 → 3 → 2 → 1 −

 $1 \rightarrow 2 \rightarrow 3 \rightarrow 4$

CC (color temperature conversion) FILTER display window

This display window indicates the current CC filter selection. When this panel is used to control the BVP-370/370P/270P camera system, the letters which are displayed here and the ND filter selections correspond as follows:

- A: Special filter*
- B: 3200 K
- C: 4300 K
- D: 6300 K
- * The special filter installed in the BVP-370/370P/270P camera head as shipped is a cross filter. If a different filter is desired as special filter, please contact your authorized Sony dealer.

CC (color temperature conversion) FILTER select buttons

Once either button is pressed, both buttons (and also the ND FILTER select buttons

Every time one or the other CC FILTER select button is pressed while lit, the CC filter selection changes as shown below. (If the button is kept pressed, the filter selection continues to change.)

$$A: \rightarrow A \rightarrow B \rightarrow C \rightarrow D \rightarrow$$

$$\Psi: \rightarrow D \rightarrow C \rightarrow B \rightarrow A \rightarrow$$

MASTER GAIN select buttons

When one of these buttons is pressed, it lights and the corresponding video gain is obtained. Use these buttons to select an appropriate video gain according to the illuminance of the subject which is to be shot.

0: 0 dB


9: 9 dB

18: 18 dB

Spare button

Not used.

1-2-6. Shutter Speed Selector Block



② SHUTTER SPEED display window

This display window indicates the current selection of shutter speed.

100: 1/100 sec for NTSC (60: 1/60 sec for PAL*)

125: 1/125 sec

250: 1/250 sec

500: 1/500 sec

1000: 1/1000 sec

2000: 1/2000 sec

* If your camera system is for the PAL system, it is necessary to change the setting of an internal switch of this panel so that "60" is displayed in place of "100". On how to change the switch setting, see Section 2 of this manual.

SHUTTER ON button

To stop the shutter operation, press this button again to make it go out. When this button is lit, you can change the camera's shutter speed using the SHUTTER SPEED select buttons .


SHUTTER SPEED select buttons

These buttons light up when the SHUTTER ON button is pressed to light up, and go out when the SHUTTER ON button is pressed again to go out.

Every time one or the other of these buttons is pressed while it is lit, the camera's shutter speed (in seconds) changes as shown below. (If the button is kept pressed, the shutter speed continues to change.)

When these buttons are unlit, pressing them do not cause the shutter speed to be changed on the part of the camera, only resulting in that the shutter speed selection on the part of this panel is changed (namely, the value of shutter speed indicated in the SHUTTER SPEED display window is replaced by a different value.)


1-2-7. LOCK Button



23 LOCK button

When this button is pressed, it lights and all buttons and knobs other than those in the iris and master black adjustment block become inoperative.

1-2-8. Knee, Gamma and Detail Adjustment Block




2 AUTO KNEE button

When this button is pressed, it lights and the AUTO KNEE circuit of the camera head is activated. When pressed again, it goes out, causing the AUTO KNEE circuit to be deactivated.

- KNEE ENB (enable) button and KNEE control knob
 - When the button is pressed, it lights and makes it possible to adjust the knee point by turning the knob. Pressing the button again makes it go out and the knob inoperative.
- GAMMA ENB (enable) button and GAMMA control knob

 When the button is pressed, it lights and makes it possible to adjust the master
 gamma by turning the knob. Pressing the button again makes it go out and the knob
 inoperative.
- DETAIL ENB (enable) button and DETAIL control knob
 When the button is pressed, it lights and makes it possible to adjust the detail for
 contour correction by turning the knob. Pressing the button again makes it go out and
 the knob inoperative.

1-2-9. Painting Block



43 ABSOLUTE button

When this button is pressed, it lights and the adjustment mode of the WHITE and BLACK control knobs changes from the relative to the absolute mode. In the absolute mode, white balance and black balance are adjusted just as indicated by the indexes (A) on the top of the WHITE and BLACK control knobs. (For details on the absolute and relative modes, see the footnote indicated by an asterisk on page 1-21(E).)


WHITE control knobs


Used to manually adjust the white balance in painting for example, after automatic white balance adjustment. From left to right, the knobs are for R, G, and B signal adjustment. A click stop is provided for the central position of each of these knobs. The knobs work in the absolute mode when the ABSOLUTE button is lit, and in the relative mode when the button is unlit. (See the footnote indicated by an asterisk on page 1-21 (E).)

(1) BLACK control knobs

Used to manually adjust the black balance in painting for example, after automatic black balance adjustment. From left to right, the knobs are for R, G, and B signal adjustment. A click stop is provided for the central position of each of these knobs. The knobs work in the absolute mode when the ABSOLUTE button is lit, and in the relative mode when the button is unlit. (See the footnote indicated by an asterisk on page 1-21 (E).)

1-2-10. Iris and Master Black Adjustment Block





3 RELATIVE button

When this button is pressed, it lights and the adjustment mode of the IRIS control lever and master black control ring (RCP-3720) or the IRIS and MASTER BLACK control knobs (RCP-3721) changes from the absolute to the relative mode. (See page 1-22(E).)

EXTENDER indicator (amber)

This indicator lights when the lens extender is used.

MASTER BLACK display window

This display window indicates the adjusted value of master black in percent. When the master black control ring (RCP-3720) or the MASTER BLACK control knob (RCP-3721) is in the absolute mode (when the RELATIVE button is unlit), it is the value absolutely corresponding to the position of the ring or knob that is indicated here.

When the camera adjustment data is recalled from a scene file with the ring or knob being in the relative mode (with the RELATIVE button being lit), it is the master black value stored in the scene file that is indicated here, regardless of the position the ring or knob is in at the time of data recalling.

4 IRIS display window

This display window indicates the f number of the current lens iris adjustment. When the iris is closed, the letters CL is displayed.

6 AUTO IRIS button

When this button is pressed, it lights and the iris is automatically adjusted according to the amount of input light. As a result, the image brightness is adjusted to a standard level.

While the button is lit, the reference value for automatic iris adjustment can be changed in the range of $\pm 1\,\mathrm{F}$ by moving the IRIS control lever (RCP-3720) or turning the IRIS control knob (RCP-3721). (The standard reference value for automatic iris adjustment is given at the central position of the lever or knob.) To exit from the automatic iris adjustment mode, press this button again. The light goes out and the IRIS control lever (or knob) becomes usable for manual iris adjustment.

Used to coarsely adjust the iris.

SENS (sensitivity) adjustment screw

To set the range of manual iris adjustment to be performed using the IRIS control lever (RCP-3720) or knob (RCP-3721), adjust this screw with a screwdriver. Turning it clockwise increases adjustment sensitivity, decreasing the range of manual iris adjustment.

Master black indicator (RCP-3720)

When the master black control ring is turned, this indicator also turns, giving an approximate indication of the adjusted master black value. However, when the RELATIVE button is lit, there is no absolute relation between indicator position and master black value.

(B) IRIS control lever/preview knob (RCP-3720)

While the AUTO IRIS button is unlit, manual iris adjustment can be performed by moving this lever. (The central value and range of adjustment can be varied using the IRIS COARSE control knob and the SENS adjustment screw respectively.) While the AUTO IRIS button is lit, this lever enables the reference value for automatic iris adjustment to be changed in the range of ±1 F. While the RELATIVE button is lit, this lever works in the relative mode. (See page 1-23(E).)

When this lever (knob) is pressed down in its axial direction, the key signal for preview is output from the PREVIEW connector (see 1-2-11.) and the picture signal from the camera under control of this panel is displayed on the monitor screen.

Master black control ring (RCP-3720)

Used to manually adjust the master black. When this ring is turned, the master black indicator salso turns, giving an approximate indication of the adjusted master black value. While the RELATIVE button significant is lit, this ring works in the relative mode. (See page 1-22(E).)

Joystick torque adjustment screw (RCP-3720)

To adjust the torque required to move the IRIS control lever (a), turn this screw with a screwdriver. Turning it clockwise makes the lever harder to move.

(RCP-3721)

While the AUTO IRIS button is unlit, this knob can be used to manually adjust the iris. (The central value and range of adjustment can be varied using the IRIS COARSE control knob and the SENS adjustment screw, respectively.)

While the AUTO IRIS button is lit, this knob can be used to vary the reference value for automatic iris adjustment in the range of ±1 F.

While the RELATIVE button is lit, this lever works in the relative mode. (See page 1-22(E).)

PREVIEW button (RCP-3721)

When this button is pressed, it lights and the key signal for preview is output from the PREVIEW connector (see 1-2-11.).


As a result, the picture signal from the camera under control of this panel is displayed on the monitor screen.

MASTER BLACK control knob (RCP-3721)

Used to adjust the master black.

While the RELATIVE button (a) is lit, this knob works in the relative mode. (See page 1-22(E).)

1-2-11. Connector Panel



CCU connector (16-pin)

This connector provides the connections for power supply and control signals. Connect it to the RCP connector (16-pin) of the camera control unit. For details, see 1-3-1 "Connection to the CCU."

2 PREVIEW connector

In the case of the RCP-3720, this connector is used to transfer the PREVIEW knob on/off signal to an external video switcher or the like.


In the case of the RCP-3721, this connector is used to transfer the PREVIEW button on/off signal to an external video switcher or the like, and also to receive the power supply for button lighting from the video switcher or the like. For details, see 1-3-2 "PREVIEW connector."

1-3. Connections

1-3-1. Connection to the CCU

Connection of this remote control panel to the camera control unit can readily be made by using a CCA-2-30 camera connecting cable (not supplied), which is 30 m long.

A different cable can also be used provided that it is equivalent to a CCA-2 cable and that it is not longer than 200 m. When employing such a connection cable, make use of the supplied 16-pin connectors complying with the wiring diagram shown below.




1-3-2. PREVIEW Connector

The PREVIEW connector is wired as shown below. It controls an external video switcher or the like.


RCP-3720

The maximum current through the switch of the PREVIEW knob is 1 mA.



RCP-3721

The power supply voltage for making the PREVIEW button light up is 5 V. The maximum current through the switch is 1 mA.



1-4. Operation

To make it possible to control your camera system from this panel, press the PANEL ACTIVE button on the panel to turn it on.

Whether which block (or control) of the panel is operative depends on the states of the PANEL ACTIVE and PARA buttons as shown below.

| State of | of button | |
|--------------|----------------------------|---|
| PANEL ACTIVE | PARA | Operative Block |
| | Lit | All blocks (including PARA button)* |
| Lit | Blinking | Only iris and master black adjustment block |
| | Unlit | All blocks (excluding PARA button)* |
| Lit | Unlit Blinking Unlit | Only PANEL ACTIVE, LOCK, and RELATIVE buttons** |


^{*} When the LOCK button is lit, it is only the iris and master black adjustment block and the LOCK button that are operative. To make the other blocks operative, press the LOCK button to turn it off.

^{**} When the LOCK button is lit, the PANEL ACTIVE button is not operative. To make the PANEL ACTIVE button operative, press the LOCK button to turn it off.

1-4-1. Automatic Adjustment of White and Black Balance

To have the white and black balance automatically adjusted, proceed as follows:

- 1 Press the AUTO IRIS button. It lights and the iris enters the automatic adjustment mode.
- f 2 Set all of the WHITE and BLACK control knobs to their central positions.*
- 3 Using the CC FILTER select buttons, select a color temperature conversion filter appropriate for the light source illuminating the subject.
- 4 If necessary, change the ND filter selection using the ND FILTER select buttons.
- 5 Shoot a white pattern. Something white (for example, white paper or wall) may be shot as a substitute.



- 6 Press the WHITE button. It lights and the white balance is automatically adjusted. When the adjustment is completed, the WHITE button goes out.**
- 7 Press the BLACK button. It lights and the black balance is automatically adjusted. When the adjustment is completed, the BLACK button goes out.**

^{*} Execution of automatic adjustment of white and black balance puts the WHITE and BLACK control knobs in the relative mode of operation. In the relative mode, the central position of each knob does not always correspond to the central value of the adjustable range. And the position where the knob was in at the time of the automatic adjustment represents the automatically adjusted value, namely the reference value for manual adjustment (or painting). That is why it is recommended to execute step 2. To switch from the relative mode back to the absolute mode in which the central position of each knob represents the central value of the adjustable range, press the RELATIVE button to turn it off.

^{**} If an error occurs during the adjustment, the button starts blinking. To stop it from blinking, press any button on this panel.

1-4-2. Iris Adjustment

While the AUTO IRIS button is lit, the iris is automatically controlled. With the AUTO IRIS button being unlit, the iris can be manually adjusted as required.

Automatic Adjustment

- 1 Set the IRIS control lever (RCP-3720) or knob (RCP-3721) to its central position.
- **2** Press the AUTO IRIS button to turn it on.

The iris is adjusted to an appropriate value according to the amount of input light.

 When the AUTO IRIS button is on, the reference value for automatic iris adjustment can be changed in the range of ±1 F by moving the IRIS control lever or turning the IRIS control knob.

Manual Adjustment

Setting the adjustable range

- 1 If the AUTO IRIS button is lit, press it to turn it off.
- 2 Set the IRIS control lever (RCP-3720) or knob (RCP-3721) to its central position.
- 3 Using the IRIS COARSE control knob, determine the center of the adjustable range for the IRIS control lever or knob.
- 4 Fully move or turn the IRIS control lever or knob in both directions to make sure of the adjustable range. To narrow or widen the range, turn the SENS adjustment screw clockwise or counterclockwise with a screwdriver.

Adjustment

Move or turn the IRIS control lever or knob to adjust the iris so that a picture of desired characteristics is obtained.

Note on the absolute mode and relative mode

The IRIS control lever (RCP-3720) or knob (RCP-3721) operates in the absolute mode when the RELATIVE button is unlit, and in the relative mode when lit. The same is true of the master black control ring (RCP-3720) or the MASTER BLACK control knob (RCP-3721).

In the absolute mode, position of the control absolutely corresponds to adjustment value and the central position always represents the central value of the adjustable range. It is not the same with the relative mode, in which the position the control was in at the time of switching from absolute to relative represents the reference value for adjustment.

If the AUTO IRIS button is pressed to turn off to switch from automatical to manual iris adjustment while the RELATIVE button is unlit (absolute mode), the automatically adjusted iris value instantaneously changes to the value corresponding to the current position of the IRIS control lever (RCP-3720) or knob (RCP-3721). This means that switching from automatic to manual may cause an undesirable sudden change in picture brightness.

However, if the RELATIVE button is pressed to turn on (relative mode) before automatic-to-manual switching, the above phenomenon does not occur because the iris value automatically adjusted at the time of the switching is held, regardless of the position of the IRIS control lever or knob at the switching time.

1-4-3. Scene File Operation

Camera adjustment and control data for a particular scene can be stored in the camera head in the form of a scene file. You can create up to five scene files operating this panel. The data stored in any of the five scene files can easily be recalled at any time to automatically adjust the camera system according to the recalled data.

The data items which can be stored in scene files are listed below.

Selection of ND filter

Selection of color temperature conversion filter.

Selection of master gain

Selection of shutter speed

On/off state of the auto knee circuit

Knee point adjustment value

Master gamma adjustment value

Detail adjustment value (for contour correction)

White balance adjustment value

Black balance adjustment value

On/off state of the auto iris circuit

Master black adjustment value

Storing scene file data

- 1 Using the controls on this panel, adjust the desired items for a camera scene for which you want to store the adjustment data in a scene file.
- 2 Press the STORE button to make it start blinking.
- 3 Press one of the file number select buttons 1 to 5 to select a scene file in which to store the adjustment data. The file number select button lights, and the adjustment data is stored into the selected file.

On completion of data storing, the STORE button stops blinking to go out while the file number select button remains lit.

 If a file already having adjustment data in it is selected, the old data is replaced with new data.

Recalling scene file data

- 1 Set all of the WHITE and BLACK control knobs to their central positions.*
- 2 Press one of the file number select buttons 1 to 5 to select a scene file to be used.

The file number select button lights, and the data in the selected file is recalled.

• If you press a file number select button which has been lit, it goes out and the camera system returns to the state it was in before the data was recalled from the corresponding file.

so execute step 2 if you want the central position of each knob to be the reference position for manual white and black balance adjustment after recalling scene file data.

Scene file data can be recalled even if you does not execute step 2. However, data recalling operation puts the WHITE and BLACK control knobs in the absolute mode,

Specifications

Connectors

CCU connector (16-pin) PREVIEW connector (6-pin)

30 V. DC Power supply 4 W

Power consumption Maximum cable length

200 m (656 feet 51/2 inches) (CCA-2 cable or equivalent) RCP-3720: 1.7 kg (3 lb 12 oz)

Weight

RCP-3721: 1.4 kg (3 lb 1 oz) Dimensions (w/h/d, including RCP-3720: $102 \times 354 \times 127$ mm $(4^{1}/_{8} \times 14 \times 5)$ inches)

projecting parts)


RCP-3721: $102 \times 354 \times 84$ mm: $(4^{1}/_{8} \times 14 \times 3^{3}/_{8} \text{ inches})$ Supplied accessories 16-pin connectors (2)

6-pin connector (1) Number plate (1 set)

Operation and maintenance manual (1) CCA-2-30 camera connecting cable Accessories not supplied

Design and specifications are subject to change without notice.

2-1. 開梱と再梱包




2-2. 標準付属品


プレビューコネクター (6ピン): 1セット PREVIEW ボタンの ON/OFF の信号をスイッチャーへ伝達します。



ナンバープレート: 1シート



CCU コネクター (16 ピン): 2セット CCU-370の RCPコネクターに接続します。電源及びコントロール信号の受け渡しをします。



Operation & Maintenance manual: 1 III

注) カメラ接続ケーブル CCA-2-30 (16 ピンコネクター付き) は, 別売りアクセサリーとなります。

2-3. 適合コネクター/ケーブル

2-3-1. コネクターの入出力信号

・コネクターの入出力信号は,次の通りです。

CCU (16 Pin)



(EXT VIEW)

| PIN | CICNIAI | ODECIPIO AUTON | |
|-----|------------------|-----------------------|--|
| No. | SIGNAL | SPECIFICATION | |
| 1 | CABLE SHIELD | | |
| 2 | GND | | |
| 3 | NC | Non-connection | |
| 4 | NC | Non-connection | |
| 5 | NC | Non-connection | |
| 6 | CCU-RCP DATA (X) | CCU SERIAL DATA | |
| 7 | CCU-RCP DATA (Y) | OUTPUT: 0.7~4.3 Vp-p, | |
| 8 | CCU-RCP DATA (G) | Zo=68Ω BALANCED | |
| 9 | DOWED (DCD) | RCP POWER: | |
| 9 | POWER (RCP) | +30 V or +24 V DC | |
| 10 | GND (RCP) | | |
| 11 | NC | Non-connection | |
| 12 | NC | Non-connection | |
| 13 | NC | Non-connection | |
| 14 | RCP-CCU DATA (X) | RCP SERIAL DATA | |
| 15 | RCP-CCU DATA (Y) | INPUT: 0.7~4.3 Vp-p, | |
| 16 | RCP-CCU DATA (G) | BALANCED | |

PREVIEW (6 Pin)



(EXT VIEW)

RCP-3720

| PIN No. | SIGNAL | SPECIFICATION |
|------------|--------|--------------------|
| 1 | NC | Non-connection |
| 2 | SW-2 | 30 V DC max 0.1 mA |
| 3 | NC | Non-connection |
| 4 | SW-1 | 30 V DC max 0.1 mA |
| 5 | NC | Non-connection |
| 6 | NC | Non-connection |


RCP-3721


| PIN No. | SIGNAL | SPECIFICATION |
|------------|--------|--------------------|
| 1 | LED(+) | 5 V DC max 1 mA |
| 2 | SW-2 | 30 V DC max 0.1 mA |
| 3 | LED(+) | 5 V DC max 1 mA |
| 4 | SW-1 | 30 V DC max 0.1 mA |
| 5 | NC | Non-connection |
| 6 | NC | Non-connection |

PREVIEW コネクター結線図

RCP-3720

RCP-3721





2-3-2. 接続コネクター

設置時、サービス時等において、コネクターパネル部の各種コネクターにケーブルを接続する際には、その先端に次に記するコネクター又は、同等品を使用して下さい。

| コネクター機能名称 | 接続するケーブル側のコネクターの部品番号および名称 | | |
|---------------|---------------------------|--|--|
| PREVIEW | | | |
| | 1-560-691-11 | PLUG, CONNECTOR 6P MALE | |
| (6P, FEMALE) | | | |
| CCU | | | |
| | 1-564-970-11 | CONNECTOR, MULTI (SQUARE) 16P MALE | |
| | | or CABLE ASSEMBLY CCA-2-30 (200 m) 16P | |
| (16P, FEMALE) | | | |

CCU-370と本パネルは、別売りのカメラ接続ケーブル CCA-2-30を使用します。これ以外のケーブルをお使いになる時は付属の16ピンコネクターを使って、下図のように配線して下さい。ケーブルの最大長は200mまでです。

※ケーブルの両端とも同じ接続

| No | No 1 2 3 4 5 6 7 |
|---|-----------------------|
| CCU Data (Y) CCU Data (G) CCU | 2 3 4 5 6 |
| 3 NC 4 NC 5 NC 6 CCU Data (X) 7 CCU Data (Y) 8 CCU Data (G) | 3 4 5 6 |
| 4 | 4 5 6 |
| 5 NC 6 CCU Data (X) 7 CCU Data (Y) 8 CCU Data (G) NC CCU Data (X CCU Data (Y CCU Data (G | 5 6 |
| 6 CCU Data (X) 7 CCU Data (Y) 8 CCU Data (G) CCU Data (G) | 6 |
| 7 CCU Data (Y) 8 CCU Data (G) CCU Data (G | |
| 8 CCU Data (G) CCU Data (G | 7 |
| | |
| 9 POWER (RCP) POWER (RCF | 8 |
| | 9 |
| 10 GND (RCP) GND (RCP) | 10 |
| 11 NC NC | 11 |
| 12 NC NC | 12 |
| 13 NC NC | 13 |
| 14 RCP Data (X) RCP Data (X | 14 |
| 15 RCP Data (Y) RCP Data (Y | 15 |
| 16 RCP Data (G) RCP Data (G | 16 |

AWG-24シールド付 ツイストペアー線3組 外周シールド付ケーブル

2-4. 設置使用環境

本機は、カメラコントロールユニット CCU-370 の RCPコネクターに接続し、調整卓に組み込んで使うことができます。

その際下記の環境内での使用に適応します。

・動作周囲温度 0°C ~ 45°C

• 保存温度 -25°C ~ +50°C

・湿度 結露状態に置かないこと。

・高温の部屋や熱源の近くは避けること。


・電源などの発熱体の上に置かないこと。


2-5. 設置スペース

2-5-1. 設置条件

• コネクターパネルの後方に約7 cm 以上の空間を設けること。 (ケーブルの損傷を防ぎます。)

2-5-2. 外形寸法 (単位 mm)






RCP-3720/3721 (WW)

2-7 (J)

2-5-3. コンソールへの取り付け方法




2-6. 基板内スイッチの機能

対応シリアルナンバー 14001番以降 (RCP-3720) 11701番以降 (RCP-3721)

MPU-53基板

• S1スイッチ



S1-1 (シャッタースピード表示)

このスイッチを「ON」にすると、操作パネル上の SHUTTER SPEED表示部に表示されるSHUTTER SPEED がPALシステムに対応して切り換わります。

\$1-2 (RGBフレアモード)

このスイッチを「ON」にすると、操作パネル上のRGB BLACK調整つまみがRGB FLARE調整つまみとして働きます。

S1-3 (ペインティング選択 1)

このスイッチを「ON」にすると、操作パネル上のAUXボタンが点灯時、KNEE ENBボタン/KNEE調整つまみ、GAMMA ENBボタン/GAMMA 調整つまみがそれぞれSATURATION ONボタン/SATURATION調整つまみ、CONTRAST ONボタン/CONTRAST 調整つまみとして働きます。


S1-4 (ペインティング選択 2)

このスイッチを「ON」にすると、操作パネル上の GAMMA ENBボタンが点灯時、RGB BLACK調整つまみ がRGB GAMMA調整つまみとして働きます。

S1-5(モニター選択)

このスイッチを「ON」にすると、SW-371基板のCN6のスイッチ入力によりCCUのPIX OUTPUTコネクターおよびWF OUTPUTコネクターの出力信号を切り換えることができます。またMSUをRCPと併用して使用する場合は、CCUのMONITOR OUTPUTコネクターからPIX OUTPUT、WF OUTPUTとは別に、WFスイッチ入力で選択した信号を出力させることができます。このときPIXスイッチは動作しません。

• S2スイッチ



S1-6 (ECSコントロール)

このスイッチを「ON」にすると、操作パネル上のSHUTTER ONボタンを押しながらSHUTTER SPEED切り換えボタンのどちらか片方を押すことにより、ECS機能とSHUTTER機能が切り換わります。またECSモード時、SHUTTER SPEED切り換えボタンにて周波数が可変できます。

S1-7 (ブラックガンマON選択)

S1-3スイッチが「ON」のとき、このスイッチを「ON」に すると操作パネル上のAUXボタンが点灯時、GAMMA ENBボタン/GAMMA調整つまみがBLACK GAMMA ON ボタン/BLACK GAMMA調整つまみとして働きます。

S1-8 (スーパーモーションモード)

このスイッチを「ON」にすると、MASTER GAINの選択が 0-6-12 dBになります。スーパーモーションシステムで使用するとき設定します。またCCU-9000付属のキートップを使用して操作パネルのMASTER GAIN切り換えボタンのキートップを交換してください。詳しくはCCU-9000のメンテナンスマニュアルの1章をご覧ください。

S2-1, S2-2 (マスターゲイン定数変更)

S2-1を「ON」にすると、MASTER GAINの選択が0-6-12 dBになります。S2-2を「ON」にすると0-3-6 dBになります。 必要に応じて操作パネル上のMASTER GAIN切り換えボタンのキートップを交換してください。


キートップ 12 ソニー部品番号 3-178-644-01 キートップ 3 ソニー部品番号 3-178-644-11 キートップ 6 ソニー部品番号 3-178-644-21

注意: S2-1、S2-2を両方「ON」にしたときはどちらの設 定も無効になります。


◎ S1-2, S1-3, S1-4 およびS1-7の設定に対応する操作ボタンの機能

| S1-2 | S1-3 | S1-4 | S1-7 | 操作ボタンの機能 | | |
|------|------|------|------|--|--|--|
| ON | OFF | OFF | OFF | RGB BLACK調整つまみが RGB FLARE調整つまみとして働く。 | | |
| ON | ON | OFF | OFF | RGB BLACK調整つまみが RGB FLARE調整つまみとして働く。 AUXボタン消灯時は通常モード。点灯時はKNEE ENBボタン/調整つまみおよびGAMMA ENBボタン/調整つまみがそれぞれSATURATION ONボタン/調整つまみ, CONTRAST ON ボタン/調整つまみとして働く。 | | |
| ON | ON | ON | OFF | RGB BLACK調整つまみが RGB FLARE調整つまみとして働く。 AUXボタン消灯時は通常モードで、このときGAMMA ENBボタンを点灯させるとRGB FLARE調整つまみが一時的にRGB GAMMA調整つまみとして働く。またAUXボタン点はKNEE ENBボタン/調整つまみおよびGAMMA ENBボタン/調整つまみがそれぞれ SATURATION ONボタン/調整つまみ、CONTRAST ONボタン/調整つまみとして働く。 | | |
| ON | ON | ON | ON | RGB BLACK調整つまみが RGB FLARE調整つまみとして働く。 AUXボタン消灯時は通常モードで、このときGAMMA ENBボタンを点灯させるとRGB FLARE調整つまみが一時的にRGB GAMMA調整つまみとして働く。またAUXボタン点灯ははKNEE ENBボタン/調整つまみおよび GAMMA ENBボタン/調整つまみがそれぞれ SATURATION ONボタン/調整つまみ、BLACK GAMMA ONボタン/調整つまみとして働く | | |
| OFF | ON | OFF | OFF | AUXボタン消灯時は通常モード。点灯時はKNEE ENBボタン/調整つまみおよびGAMMA ENBボタン/調整つまみがそれぞれSATURATION ONボタン/調整つまみ, CONTRAST ONボタン/調整つまみとして働く。 | | |
| OFF | ON | ON | OFF | AUXボタン消灯時は通常モードで、このときGAMMA ENBボタンを点灯させるとRG BLACK調整つまみが一時的にRGB GAMMA調整つまみとして働く。またAUXボタン はKNEE ENBボタン/調整つまみおよび GAMMA ENBボタン/調整つまみがそれぞれ SATURATION ONボタン/調整つまみ, CONTRAST ONボタン/調整つまみとして働く | | |
| OFF | ON | ON | ON | AUXボタン消灯時は通常モードで、このときGAMMA ENBボタンを点灯させるとRGB BLACK調整つまみが一時的にRGB GAMMA調整つまみとして働く。またAUXボタン点 はKNEE ENBボタン/調整つまみおよび GAMMA ENBボタン/調整つまみがそれぞれ SATURATION ONボタン/調整つまみ、BLACK GAMMA ONボタン/調整つまみとして個 | | |
| OFF | OFF | ON | OFF | GAMMA ENBボタンを点灯させるとRGB BLACK調整つまみが一時的にRGB GAMMA調整つまみとして働く。 | | |

[コントロールパネル部]




2-7. システム接続




SECTION 2 INSTALLATION

2-1. PACKING AND UNPACKING



2-2. SUPPLIED ACCESSORIES

Preview connector (6-pin) × 1
 Transmits the PREVIEW button ON/OFF signal to the switcher.








ullet Operation and Maintenance manual imes 1

CCU Connector (16-pin) × 2
 Connects to the RCP connector of the CCU-370, and provides connections for power supply and control signals.

Note: Camera connection cable CCA-2-30 (with 16-pin connector) is an optional accessory.




connector) is an optional accessory.

2-3. CONNECTORS AND CABLES

2-3-1. Connector Input/Output Signals

The main connector Input/Output signals are as follows.

CCU (16-pin)



(EXT VIEW)

| PIN No. | SIGNAL | SPECIFICATION |
|------------|------------------|-------------------------------|
| 1 | CABLE SHIELD | |
| 2 | GND | |
| 3 | NC | Non-connection |
| 4 | NC | Non-connection |
| 5 | NC | Non-connection |
| 6 | CCU-RCP DATA (X) | CCU SERIAL DATA |
| 7 | CCU-RCP DATA (Y) | OUTPUT: 0.7~4.3Vp-p, |
| 8 | CCU-RCP DATA (G) | Zo=68 Ω BALANCED |
| 9 | POWER (RCP) | RCP POWER: +30V or +24V DC |
| 10 | GND (RCP) | |
| 11 | NC | Non-connection |
| 12 | NC | Non-connection |
| 13 | NC | Non-connection |
| 14 | RCP-CCU DATA (X) | RCP SERIAL DATA |
| 15 | RCP-CCU DATA (Y) | INPUT: 0.7~4.3Vp-p, |
| 16 | RCP-CCU DATA (G) | BALANCED |

PREVIEW (6-pin)



(EXT VIEW)


RCP-3720

| PIN No. | SIGNAL | SPECIFICATION |
|------------|--------|------------------|
| 1 | NC | Non-connection |
| 2 | SW-2 | 30V DC max 0.1mA |
| 3 | NC | Non-connection |
| 4 | SW-1 | 30V DC max 0.1mA |
| 5 | NC | Non-connection |
| 6 | NC | Non-connection |

RCP-3721

| PIN No. | SIGNAL | SPECIFICATION |
|------------|---------|------------------|
| 1 | LED (+) | 5V DC max 1mA |
| 2 | SW-2 | 30V DC max 0.1mA |
| 3 | LED (+) | 5V DC max 1mA |
| 4 | SW-1 | 30V DC max 0.1mA |
| 5 | NC | Non-connection |
| 6 | NC | Non-connection |

Note: The PREVIEW connector is wired as show in the diagram below, and controls the external video switcher.



RCP-3720

RCP-3720/3721(WW)


2-3-2. Connectors

When cable with connectors are set to the respective connectors on the connector panel during installation or service, the specified or equivalent connectors with cables, or the specified cable assemblies should be used, these are listed as follows;

| Connector function | | Parts | No. and name of connector with cable |
|--------------------|---------------|--------------|---|
| PREVIEW | (6P, FEMALE) | 1-560-691-11 | PLUG, CONNECTOR 6P MALE |
| CCU | (16P, FEMALE) | 1-564-970-11 | CONNECTOR, MULTI (SQUARE) 16P MALE or CABLE ASSEMBLY CCA-2-30 (200m) 16P |

Connection between the CCU-370 and the remote control panel can be made with the CCA-2-30 camera connecting cable which is optionally available. Or, if you wish to use cable other than this, make use of the supplied 16-pin connectors by wiring them as shown in the diagram below. The maximum cable length should be 20 m.

• Make the same connections at both ends of the cable.



Cable should contain three twisted pairs, each surrounded by AWG-24 shielded wire. These, in turn, should be surrounded by outer shield.

2-4 (E) RCP-3720/3721(WW)

2-4. OPERATING ENVIRONMENT

The set can be connected to the RCP connector of the camera control unit CCU-370 and installed into the control console. The set should be operated in the following environments.

Operating temperature

0°C to +45°C

Storage temperatune

-25°C to +50°C


- Avoid exposing the set to rain or moisture.
- Avoid placing the set in hot places.
- Avoid placing the set near a heat source such as a power source.

2-5. INSTALLATION SPACE


2-5-1. Installation Conditions

Provide a space of 7 cm or more behind the connector panel. (This prevents cable breakdown.)

2-5-2. Outside Dimensions (mm)



2-6 (E)



RCP-3720/3721 can be installaed into the control console using the brackets which are supplied with product. 0 C


2-8 (E)

2-6. FUNCTION OF SWITCH ON PC BOARD

Applicable Serial No. 14001 and Higher (RCP-3720) 11701 and Higher (RCP-3721)

MPU-53 board

S1 switch



\$1-1 (SHUTTER SPEED INDICATION)

When this switch is turned ON, the shutter speed indication in the SHUTTER SPEED display window on the control panel changes for the PAL system.

\$1-2 (RGB FLARE MODE)

When this switch is turned ON, the RGB BLACK control knobs on the control panel function as the RGB FLARE control knobs.

\$1-3 (PAINTING SELECT 1)


When this switch is turned ON, the KNEE ENB button/KNEE control knob and GAMMA ENB button/GAMMA control knob on the control panel function as the SATURATION ON button/SATURATION control knob and CONTRAST ON button/CONTRAST control knob respectively while the AUX button is lit.

\$1-4(PAINTING SELECT 2)

When this switch is turned ON, the RGB BLACK control knobs on the control panel function as the RGB GAMMA control knobs while the GAMMA ENB button is lit.

\$1-5 (MONITOR SELECT)

When this switch is turned ON, the switching input at CN6/SW-371 board selects the signals to be output from the PIX OUTPUT and WF OUTPUT connectors of the CCU. When an MSU and RCP are used together, the signal which was selected by the WF switching input can be output from the MONITOR OUTPUT connector, independently of the PIX and WF outputs. In this state, the PIX switching input becomes disable.



\$1-6 (ECS CONTROL)

When this switch is turned ON, the ECS and SHUTTER functions change alternately every time either of SHUTTER SPEED select buttons on the control panel is pressed while pressing the SHUTTER ON button. In the ECS mode, the frequency changes by pressing the SHUTTER SPEED select buttons.

\$1-7 (BLACK GAMMA ON SELECT)

When the switch S1-3 and this switch are turned ON, the GAMMA ENB button/GAMMA control knob on the control panel functions as the BLACK GAMMA ON button/BLACK GAMMA control knob while the AUX button is lit.

\$1-8 (SUPERMOTION MODE)

When this switch is turned ON, the video gain $0/6/12~\mathrm{dB}$ is selected by the MASTER GAIN select buttons on the control panel for the supermotion system. To replace key tops of the MASTER GAIN select buttons is also required. For details, refer to a CCU-9000/9000P maintenance manual, Section 1.

\$2-1, \$2-2 (MASTER GAIN VALUE CHANGE)

When the switch S2-1 is turned ON, the video gain 0/6/12 dB is selected by the MASTER GAIN select buttons on the control panel. When the S2-2 is turned ON, 0/3/6 dB is selected. Replace key tops of the MASTER GAIN select buttons according to necessary.


| Key top 12 | Sony Part No. 3-178-644-01 |
|------------|----------------------------|
| Key top 3 | Sony Part No. 3-178-644-11 |
| Key top 6 | Sony Part No. 3-178-644-21 |

Note: When S2-1 and S2-2 are both turned ON, either becomes invalid.


Operating Button functions according to Switch Settings of S1-2, S1-3, S1-4 and S1-7.

| S1-2 | S1-3 | S1-4 | S1-7 | Functions of Operating Buttons |
|------|------|------|------|--|
| ON | OFF | OFF | OFF | RGB BLACK control knobs function as RGB FLARE control knobs. |
| ON | ON | OFF | OFF | RGB BLACK control knobs function as RGB FLARE control knobs. When AUX button is unlit, a unit is in normal mode. When lit, KNEE ENB button/control knob and GAMMA ENB button/control knob function as SATURATION ON button/control knob and CONTRAST ON button/control knob respectively. |
| ON | ON | ON | OFF | RGB BLACK control knobs function as RGB FLARE control knobs. When AUX button is unlit, a unit is in normal mode. When GAMMA ENB button is lit while AUX button is unlit, RGB FLARE control knobs temporarily function as RGB GAMMA control knobs. When AUX button is lit, KNEE ENB button/control knob and GAMMA ENB button/control knob function as SATURATION ON button/control knob and CONTRAST ON button/control knob respectively. |
| ON | ON | ON | ON | RGB BLACK control knobs function as RGB FLARE control knobs. When AUX button is unlit, a unit is in normal mode. When GAMMA ENB button is lit while AUX button is unlit, RGB FLARE control knobs temporarily function as RGB GAMMA control knob. When AUX button is lit, KNEE ENB button/control knob and GAMMA ENB button/control knob function as SATURATION ON button/control knob and BLACK GAMMA ON button/control knob respectively. |
| OFF | ON | OFF | OFF | When AUX button is unlit, a unit is in normal mode. When lit, KNEE ENB button/control knob and GAMMA ENB button/control knob function as SATURATION ON button/control knob and CONTRAST ON button/control knob respectively. |
| OFF | ON | ON | OFF | When AUX button is unlit, a unit is in normal mode. When GAMMA ENB button is lit while AUX button is unlit, RGB BLACK control knobs temporarily function as RGB GAMMA control knobs. When AUX button is lit, KNEE ENB button/control knob and GAMMA ENB button/control knob function as SATURATION ON button/control knob and CONTRAST ON button/control knob respectively. |
| OFF | ON | ON | ОИ | When AUX button is unlit, a unit is in normal mode. When GAMMA ENB button is lit while AUX button is unlit, RGB BLACK control knobs temporarily function as RGB GAMMA control knobs. When AUX button is lit, KNEE ENB button/control knob and GAMMA ENB button/control knob function as SATURATION ON button/control knob and BLACK GAMMA ON button/control knob respectively. |
| OFF | OFF | ON | OFF | When GAMMA ENB button is lit, RGB BLACK control knobs temporarily function as RGB GAMMA control knobs. |

[CONTROL PANEL BLOCK]



2-7. SYSTEM CONFIGURATION



2 - 10 (E)

第3章 サービスインフォメーション

3-1. 主要部品の交換方法

3-1-1. 外装の外し方

①KNOBを6個外します。

②ねじ (+B3×5) 2本を外し, RACK BRACKET (2) を それぞれ外します。

③SUB CHASSIS (B2) を止めているねじ (+B3×5) 2本 を外します。

④ねじ (+B3×5) 4本を外すと PANEL ASSY (J2) が外れます。 (RCP-3720のみ)


ねじ (+B 3×5) 4 本を外すと PANEL ASSY (D2) が外れます。 (RCP-3721 のみ)

⑤DSP-27 基板のコネクター CN1 を外します。 (RCP-3720 のみ)

DSP-28 基板のコネクター CN1 を外します。 (RCP-3721 のみ)


⑥SW-371 基板のコネクター CN5 と MPU-53 基板のコネクター CN4 を外します。

⑦ねじ (+B3×5) 4本を外し, CONTROL PANEL (B2) を外します。




3-1-2. ジョイスティックボリュームの交換方法 (RCP-3720のみ)


1. ねじ(PRECISION+P2.6×6)1本を外し, COVER TUBE を外します。




2. COVER FIXED SHAFTを外します。ねじ (SETSCREW 2.6×3) 1本を外し, ADJUSTMENT TUBE を外します。




3. ボリュームを止めているナット及びねじ (SETSCREW 2.6×3) 2本を外し, VR FIXED TUBEを外します。



4. ボリュームに接続しているハーネスの半田付けを外します。



5. CONTROL PANEL (J2) を外すときは、ねじ (SET-SCREW 2.6×3) 2本を外し、LEVER FIXED TUBE を外します。



6. 取り付けは取り外しと逆の手順で行います。

3-1-3、 コントロールパネルの外し方

[RCP-3720]

①3-1-2. ジョイスティックボリュームの交換方法を参照 してジョイスティック ASSY を外します。

②ねじ (+B3×5) 2本を外して COVER (S) を外します。


③ねじ(+B3×5)4本を外して,CONTROL PANEL(J2)を外します。


[RCP-3721]

①KNOB 2個を外します。

②ねじ (+B3×5) 2本を外して COVER (S) を外します。

③ねじ (+B3×5)4本を外してCONTROL PANEL (D2)を外します。





3-2. サービス上の注意事項

3-2-1. PROM IC

PROM ICにはオリジナル品名の末尾にそのプログラムの名称が記載されています。

又, バージョン変更された場合, この末尾の名称が変わります。オリジナル品名のみ(プログラム化されていない) は絶対に使用しないこと。

尚,各基板に使われているICは全てソケット化しています。

3-2-2. 補修用部品の注意事項

(1) 安全重要部品

回路図,分解図,電気部品表中, ▲印および >>>>> で 囲まれた部品は安全性を維持するために重要な部品で す。従って、これらの部品を交換するには必ず指定の 部品と交換して下さい。

(2) 部品の共通化

ソニーから供給される部品はセットに実装されている ものと異なることがあります。これは部品の共通化, 改良等によるものです。分解図や電気部品表中には現 時点での共通化された部品が記載されています。

(3) 部品在庫

分解図,電気部品表中,SP欄がSで示されている部品は常時在庫しています。

SP欄が "O" で示されている部品は交換頻度が低い部品であるので在庫しないことがあり、納期が長くなることがあります。

(4) コンデンサ,インダクタ,抵抗の単位


回路図,分解図,電気部品表中,特に明記したものを 除き,下記の単位は省略されています。

コンデンサ: μF インダクタ: μH 抵抗 : Ω

3-2-3. 治工具

ICテストクリップ


TC-16 ソニー部品番号 J-6041-770-A TC-20 ソニー部品番号 J-6041-780-A



チェック, 調整時に DIP タイプ IC の足にオシロスコープ のプローブをかけるのに便利です。


3-2-4. チップ部品交換時の注意事項

コンデンサー




端を電極が覆っている

抵抗



側面に電極がない

ダイオード, トランジスタ



用意する治具: 20 W程度の半田ゴテ (可能ならば,コテの

温度が270°±10°Cにコントロールできる

温度コントローラーを使用する。)

編組線(ソルダートール)

半田 (0.6 mm 径のものが望ましい)

ピンセット

半田付け条件: コテ温度 270°±10°C

端子1か所を2秒以内に半田付けすること。

手順

1. 抵抗又はコンデンサーを外す場合は、半田ゴテの先を チップ部品の上にのせて部品を加熱し、半田が溶けた 状態で横にずらして外します。

ダイオード又はトランジスターの場合は、チップ部品の片側に足2本が出ている方を同時に加熱し、半田が溶けたら部品を上に起こして足2本を外します。次にもう片方の足を外すようにします。

- 2. 外した後, ランド表面を平らにするために, 編組線を 使って半田を吸い取って下さい。
- 3. 取り外した部分のパターンはがれ、隣接半田付け部の ダメージ、ブリッジなどがないことを目視にて確認し ます。
- 4. パターンにうすく予備半田します。
- 5. 新しいチップ部品をパターンにのせ両端を半田付けし ます

取り外したチップ部品は再度使用しないこと。


詳しくは、ソニー技術推進部発行の「チップ・マニュアル」 ソニー部品番号9-963-089-01を参照して下さい。

SECTION 3 SERVICE INFORMATION

3-1. REPLACEMENT OF MAIN PARTS


3-1-1, Cabinet Removal

- 1) Remove six knobs.
- ② Remove two screws (+B3×5) and remove RACK BRACKET(2) respectively.
- ③ Remove two screws (+B3×5) securing SUB CHASSIS (B2).
- Remove four screws (+B3×5) and remove PANEL ASSY (J2). (only for RCP-3720)
 Remove four screws (+B3×5) and remove PANEL ASSY (D2). (only for RCP-3721)
- Disconnect the connector CN1 on the DSP-27 board.
 (only for RCP-3720)
 Disconnect the connector CN1 on the DSP-28 board.
 (only for RCP-3721)
- 6 Disconnect two connectors, CN5 on the SW-371 board and CN4 on the MPU-53 board.
- Remove four screws (+B3x5) and remove CONTROL PANEL (B2).




3-1-2. Replacement of Joystick Control (only for RCP-3720)


1 Remove the screw (PRECISION +P2.6×6) and remove COVER TUBE.




2 Unscrew COVER FIXED SHAFT. Remove the setscrew (2.6×3) and remove ADJUSTMENT TUBE.



3 Remove the nut securing the control and remove the setscrew (2.6×3). VR FIXED TUBE will be removed.



4 Desolder harness connected to the control.



5 When removing CONTROL PANEL (J2), remove two setscrews (2.6×3) and remove LEVER FIXED TUBE.



6 When mounting a new control, reverse the procedures for removal.


3-1-3 Removal of Control Panels


[RCP-3720]

- ① Remove joystick ASSY, referring to Section 3-1-2. Replacement of Joystick Control.
- ② Remove two screws (+B3×5) and remove COVER (S).
- 3 Remove four screws (+B3×5) and remove CONTROL PANEL (J2).

[RCP-3721]

- Remove two knobs.
- ② Remove two screws (+B3×5) and remove COVER (S)
- 3 Remove four screws (+B3×5) and remove CONTROL PANEL (D2).





3-2. NOTE ON MAINTENANCE SERVICES

3-2-1, PROM IC

Each PROM IC on the PC board has a suffix to its original designation. This suffix may change according to improvement of IC. Never use an IC having no suffix to its original designation, because its memory has not been programmed. Each PROM IC is mounted to the PC board via socket.

3-2-2. Note On Replacement Parts

1. Safety Related on Components Warning Components identified by shading marked with A on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony Parts whose parts numbers appear as shown in this manual or in service manual supplements published by Sony.

2. Standardization of Parts

Replace Parts that are supplied from Sony Parts Center can sometimes have different shape and external appearance than what are actually used in equipment. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts."

- · This manual's exploded view and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present."
- · Regarding engineering parts and diagrams changes in our engineering department, refer Sony service bulletins and service manual supplements.

3. Stocked of Parts

The parts marked with "S" in the SP column of the exploded views and electrical spare parts list are normally required for routine service work. Order for parts marked with "O" will be proceed, but allow for additional delivery time.


4. Units of Capacitors. Inductors, and Resistors The following units are omitted in the schematic diagrams, exploded views, and electrical parts lists unless otherwise specified;

Capacitor: uF Inductor : µH Resistor Ω

3-2-3. Fixture

IC Test Clip


TC-16 Sony Parts No. J-6041-770-A TC-16 Sony Parts No. J-6041-780-A



This clip is convenient for contacting an oscilloscope probe with each leg of DIP type IC when the IC is checked and adjusted.

3-2-4 Replacement of Chip Parts


Capacitor



Resistor Black (resistance side)

Not covered with electrode.

Diode and transistor



Tools required

- Soldering iron of approx. 20W (Use a temperature controller, if possible, which can control the iron temperature to 270 ± 10 °C.)
- Desoldering metal braid (Parts No. 7-641-300-81)
- Solder (A solder of 0.6mm in diameter is recommended.)
- Tweezers

Soldering conditions

- Iron temperature of 270 ± 10 °C
- Soldering should be performed within two seconds.

Procedures

- 1. To remove a resistor or capacito, place the tip of a soldering iron on chip parts to heat the parts, and then move it horizontally for removal while being desoldered. For removal of a diode or transistor, heat the one side, with two pins, of chip parts at the same time. Set the parts up when desoldered and remove two pins. And then remove the pin on another side.
- 2. Absorb solder by using a desoldering metal braid to smooth the land surface after removal.
- 3. Confirm by visual check that no trace is come off, no adjacent parts is damaged and no bridging occur.
- 4. Perform a thin pretinning on the trace.
- 5. Place new chip parts on the trace to solder its both sides.

Note: Do not reuse parts which have been removed.


For details, see CHIP COMPONENTS manual (Parts No. 9-963-089-01) prepared by Sony Corporation.


3-5 (E)

BOARD LAYOUT

RCP-3720

RCP-3721





RCP-3720/3721 (W. W)

A-1

В


C


n

1

1

BLOCK DIAGRAM






RCP-3720/3721 (W.W)

A-6

Ε


FRAME (1/2) Ser No.10001-10399
MPU-53 BOARD




1-632-784-11 SOLDERING SIDE

2

3





1-632-784-11 SOLDERING SIDE

A-10 (a)

RCP-3720/3721 (W. W)

C


.

D


Ε


MPU-53 BOARD

FRAME (1/2) Ser No.10401-11100 RCP-3720



1-632-784-12 SOLDERING SIDE





1-632-784-12 SOLDERING SIDE


RCP-3720/3721 (W.W)

FRAME (1/2) MPU-53 BOARD

5


3

Ser No.11101-11700 RCP-3720 10401-10700 RCP-3721



1-632-784-13 SOLDERING SIDE






1-632-784-13 SOLDERING SIDE

RCP-3720/3721 (W.W)

A-10(c)

FRAME (1/2) MPU-53 BOARD

RCP-3720 Ser No.11701-RCP-3721 10701-




A-9 (d)

1-632-784-14 SOLDERING SIDE



5




1-632-784-14 SOLDERING SIDE

A-10 (d)

RCP-3720/3721 (W.W)

FRAME WIRING (1/2)
MPU-53 BOARD




D

Ε

G

C

D



2

1

3

5

B-\PCP3720-FRAME/M#1

A-13


Ε

G


Н

SW-371 BOARD

DSP-27 BOARD (FOR RCP-3720)







1-632-788-11 SOLDERING SIDE

IR-12 BOARD (FOR RCP-3720)




1-632-787-11 SOLDERING SIDE

LED-98 -632 -786-11


LED-98 BOARD

1-632-786-11 SOLDERING SIDE

DSP-28 BOARD (FOR RCP-3721)



1-632-789-11 SOLDERING SIDE



1-632-789-11 SOLDERING SIDE

1-632-785-11 SOLDERING SIDE

B-RCP3720/3721-FRAME#2/MOUNT


A-14 (a)

A-15 (a)




LED-98 1-632 -786-11 JAPAN


1-632-786-11 SOLDERING SIDE



SW-371 BOARD



1-632-785-11 SOLDERING SIDE



1-632-785-11 SOLDERING SIDE

A-16 (a)

RCP-3720/3721 (W. W)

A-15 (a)

G

Н

SW-371 (1-632-785-11)

RV1 RV2 RV3 RV4 RV5 RV6 RV7 RV8 RV9

N-4 N-4 H-1 J-1 H-1 H-2 F-2 F-1 F-1 J-5 K-5 JK-7 LM-4


CN1 CN2 CN3 CN4 CN5 CN6 CN7 CN8 CN9

IC1 IC2 IC3 IC4 IC5 IC6 IC7 IC8 IC9 IC10 IC11


E

F


DSP-27 BOARD (FOR RCP-3720)





1-632-788-11 SOLDERING SIDE



1-632-788-11 SOLDERING SIDE








1-632-787-11 SOLDERING SIDE

LED-109 BOARD




1-634-923-11 SOLDERING SIDE

DSP-28 80ARD (FOR RCP-3721)




1-632-789-11 SOLDERING SIDE



1-632-789-11 SOLDERING SIDE

SW-371 BOARD



1-632-785-12 SOLDERING SIDE

B-RCP3720/3721-FRAME#2/MOUNT

A-14(b)

A-15 (b)

1-632-7

LED-98 BOARD


LED-98

1-632-786-12 SOLDERING SIDE

LED-109 BOARD




1-634-923-11 SOLDERING SIDE




Ε

SW-371 BOARD



1-632-785-12 SOLDERING SIDE



SW-371 (1-632-785-12)

Q47 Q48 Q49 Q50 Q51 Q52 Q53 Q53 Q54 Q55 Q57 Q57 Q61 Q62 Q62 Q63 Q64 Q65 Q66 Q67 Q70 Q71 Q72 Q73 Q74 Q75 Q76 Q76

H - 3 G - 3 I - 7 I - 7 F - 7 F - 6 F - 5 C - 7 D - 6 D - 1 D - 1 D - 6 D - 5 D - 2

H-1 H-1 J-1 H-1 F-2 G-1 F-1 J-5 J-5 J-5 J-5 J-5 J-7 K-7 K-7 H-7 H-7

CN1 CN2 CN3 CN4 CN5 CN6

D1 D2 D3 D4 D5 D6 D7 D8 D9 D10 D11 D12 D13 D14 D16 D17 D18 D19 D20 D21 D22

IC1 IC2 IC3 IC4 IC5 IC6 IC7 IC8 IC9 IC10 IC11

1-632-785-12 SOLDERING SIDE

A-15 (b) A-16 (b) RCP-3720/3721 (W.W) J

1


5 .

3


ō

Ser No.11101-11700 RCP-3720 10401-10700 RCP-3721


DSP-27 BOARD (FOR RCP-3720)




1-632-788-11 SOLDERING SIDE



1-632-788-11 SOLDERING SIDE





LED-98 BOARD

1-632-786-12 SOLDERING SIDE


1-632-787-11 SOLDERING SIDE

LED-109 BOARD




1-634-923-11 SOLDERING SIDE


DSP-28 BOARD (FOR RCP-3721)



1-632-789-11 SOLDERING SIDE



1-632-789-11 SOLDERING SIDE




SW-371 BOARD

1-632-785-13 SOLDERING SIDE

B-RCP3720/3721-FRAME#2/MOUNT

A-14(c)

A-15(c)






1-632-786-12 SOLDERING SIDE

1-6:


LED-109 BOARD




1-634-923-11 SOLDERING SIDE



SW-371 BOARD



1-632-785-13 SOLDERING SIDE



1-632-785-13 SOLDERING SIDE

RCP-3720/3721 (W.W)

A-15(c)

A-16(c)

SW-371 (1-632-785-13)

Q45 Q47 Q48 Q49 Q50 Q51 Q52 Q53 Q54 Q55 Q56 Q67 Q68 Q69 Q67 Q67 Q67 Q72 Q74 Q75 Q77

RV1 RV2 RV3 RV4 RV5 RV6 RV7 RV8 RV9


FRAME (2/2)

l


. .

Ser No.11701-RCP-3720 RCP-3721 10701-


DSP-27 BOARD (FOR RCP-3720)



1-632-788-11 SOLDERING SIDE



1-632-788-11 SOLDERING SIDE



1-632-787-11 SOLDERING SIDE




LED-109 BOARD

1-632-786-13 SOLDERING SIDE


LED-98 BOARD

1-634-923-12 SOLDERING SIDE


DSP-28 BOARD (FOR RCP-3721)



1-632-789-11 SOLDERING SIDE



1-632-789-11 SOLDERING SIDE



1-632-785-14 SOLDERING SIDE

A-14(d)

A-15(d)

1-632-

076_071_073_076






1-632-786-13 SOLDERING SIDE


LED-109 BOARD




1-634-923-12 SOLDERING SIDE



SW-371 BOARD



1-632-785-14 SOLDERING SIDE



SW-371 (1-632-785-14)

Q40
Q41
Q42
Q43
Q44
Q45
Q46
Q47
Q48
Q50
Q51
Q52
Q53
Q54
Q55
Q56
Q57
Q68
Q69
Q60
Q61
Q62
Q63
Q64
Q65
Q67
Q68
Q69
Q70
Q71
Q72
Q73
Q74
Q75
Q76

RVI RV2 RV3 RV4 RV5 RV6 RV7 RV8 RV9

CN1 CN2 CN3 CN4 CN5 CN6 CN14 CN15 CN16

D1 D2 D3 D4 D5 D6 D9 D10 D11 D12 D13 D14 D15 D16 D17 D18 D19 D20 D21 D22 D23 D24 D25

IC1 IC2 IC3 IC4 IC5 IC6 IC7 IC8 IC9 IC10 IC11 IC12

1-632-785-14 SOLDERING SIDE

A-15(d)

A-16(d)

A-16(d)

BCP-3720/3721(W.W)

I

J


A-18

RCP-3720/3721 (W. W)

A-17

C D E F G

D



A-18

Ε

е і п і

B-\RCP3720-FRAME/M#2

SECTION B SEMICONDUCTOR PIN ASSIGNMENTS

 TC5068BP
 B-6

 TC74HC4028F
 B-6

 TL7700CPS
 B-6

 TLP112
 B-2

 TLUG163
 B-2

 TLUG164
 B-2

 TLUY164
 B-2


TMP82C79M-2 B-8
TMS27C256-25 B-9
uPD7004C B-9


PAGE


The circuit diagram of IC is obtained from the IC data book published by the manufacturer.

TYPE

| TYPE | PAGE |
|---|---|
| 1\$2835 · · · · · · · · · · · · · · · · · · · | |
| 1SS123 · · · · · · · · · · · · · · · · · · · | |
| 2SA1162 ····· | B-2 |
| 2SC2712G · · · · · · · · · · · · · · · · · · · | B-2 |
| 2SD596 | B-2 |
| CXD1095Q | B-3 |
| CXK5864BM-10L | B-3 |
| DTA143XK | B-2 |
| DTC143XK····· | B-2 |
| GL-3HY8 | B-2 |
| HD64180ZF····· | B-4 |
| LA-301ML | B-2 |
| LB-202ML · · · · · · LB-203ML · · · · · · · · · · · · · · · · · · · | |
| LD-001MG · · · · · · LD-101MG · · · · · · · · · · · · · · · · · · · | B-2 B-2 |
| MC14053BF ····· | B-4 |
| MSM80C49GS | B-5 |
| RD ? ?MB ? | B-2 |
| SLP281C-50 ····· | B-2 |
| SN74HC04NS | B-6 B-6 B-6 B-6 B-6 B-6 B-6 |










| PIN NO. | IN | OUT | SYMBOL | PIN NO. | IN | OUT | SYMBOL | PIN NO. | IN | OUT | SYMBOL | PIN NO. | IN | OUT | SYMBOL |
|------------|----|-----|--------|------------|----|-----|-----------|------------|----|-----|--------|------------|----|-----|----------|
| 1 | | | NC | 17 | 0 | 0 | PC6 | 33 | | | NC | 49 | 0 | 0 | PXO |
| 2 | | | NC | 18 | 0 | 0 | PC7 | 34 | | Г | NC | 50 | 0 | 0 | PX1 |
| 3 | 0 | 0 | PBi | 19 | | | NC | 35 | 0 | 0 | 03 | 51 | | T | - NC |
| 4 | 0 | 0 | PB 2 | 20 | 0 | 0 | PDO | 36 | 0 | 0 | D4 | 52 | 0 | 0 | PX2 |
| 5 | 0 | 0 | PB3 | 21 | 0 | 0 | PD1 | 37 | 0 | 0 | D5 | 53 | 0 | 0 | PX3 |
| 6 | 0 | 0 | PB4 | 22 | 0 | 0 | PD2 | 38 | 0 | 0 | D6 | 54 | 0 | 0 | PAO |
| 7 | 0 | 0 | P8 5 | 23 | 0 | 0 | PD3 | 39 | 0 | 0 | D7 | 55 | 0 | 0 | PAI |
| 8 | 0 | 0 | P96 | 24 | 0 | 0 | PD4 | 40 | 0 | | CLR | 56 | 0 | 0 | PA2 |
| 9 | 0 | 0 | PB7 | 25 | | | GND | 41 | 0 | | RST | 57 | | П | GND |
| Ю | | | GND | 26 | 0 | | VDD (+5V) | 42 | | | GND | 58 | 0 | | V001+5VI |
| 11 | 0 | 0 | PCO | 27 | 0 | 0 | PD5 | 43 | 0 | | WR | 59 | 0 | 0 | PA3 |
| 12 | 0 | 0 | PC1 | 28 | 0 | 0 | PD6 | 44 | 0 | | RD | 60 | 0 | 0 | PA4 |
| 13 | 0 | 0 | PC2 | 29 | 0 | 0 | PD7 | 45 | 0 | | C5 | 61 | 0 | 0 | PA5 |
| 14 | 0 | 0 | PC3 | 30 | 0 | 0 | DO | 46 | 0 | 1 | AO | 62 | 0 | 0 | PA6 |
| 15 | 0 | 0 | PC4 | 31 | ō | 0 | DI | 47 | 0 | | A1 | 63 | 0 | 0 | PA7 |
| 16 | 0 | 0 | PC5 | 32 | 0 | 0 | D2 | 48 | 0 | | A2 | 64 | 0 | 0 | PBO |

| | | cs | RD | WR | A2 | A1 | AO | MODE |
|------------|----------------|-------|-------|------|------|------|------|----------------------|
| 1 | PAO 55 | | | - | _ | _ | - | MODE |
| | PA 1 55 | 0 | 0 | 1 | 0 | 0 | 0 | PORT A - DATA BUS |
| | PA 3 59 | 0 | 0 | 1 | 0 | 0 | 1 | PORT B - DATA BUS |
| | PA 4 60 | 0 | 0 | 1 | 0 | 1 | 0 | PORTC - DATA BUS |
| 1 | PA5 61 | 0 | 0 | 1 | 0 | 1 | 1 | PORT D- DATA BUS |
| 00 | PA6 62 | 0 | 0 | 1 | 1 | 0 | 0 | PORT X - DATA BUS |
| 11 D1 | PA7 63 | 0 | 0 | 1 | 1 | 0 | 1 | |
| 02 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | |
| 55 D3 | 980 64 | 0 | 0 | 1 | 1 | 1 | 1 | |
| D4 | PB1 3 | 0 | 1 | 0 | 0 | 0 | 0 | DATA BUS-PORT A |
| D5 | PB2 | _ | - | - | - | - | - | |
| D6 | P83 5 | 0 | 1 | 0 | 0 | 0 | 1 | DATA BUS-PORT B |
| 07 | P84 6 | 0 | 1 | 0 | 0 | 1 | 0 | DATA BUS-PORT C |
| 9 BV0 | PB5 7 PB6 8 | 0 | 1 | 0 | 0 | 1 | 1 | DATA BUS PORT D |
| | | 0 | 1 | 0 | 1 | 0 | 0 | DATA BUS-PORT X |
| PX1 PX2 | P87 | 0 | 1 | 0 | 1 | 0 | 1 | |
| 3 PX3 | PC0 11 | 0 | 1 | 0 | 1 | 1 | 0 | DATA BUS + CTL REG.1 |
| 7^3 | PC1 12 | 0 | 1 | 0 | 1 | 1 | 1 | DATA BUS +CTL REG.2 |
| 6 AO | PC2 13 | 1 | x | X | X | X | x | DATA BUS : HI-Z |
| A1 | pc2 14 | | | | | | | 57777 500 ; 111 & |
| 8 A2 | BC4 15 | | | W L | | | | |
| _ | PC5 16 | | | GH 1 | | | | |
| 5 cs | PC6 17 | | | T'NC | | | | |
| 4 RD | PC7 18 | H1-2 | 2. HI | GH | IMPE | DAN | CE | |
| WR | | | | | | | | |
| 1 | PD0 20 | - 1 | | | | | | |
| RST | PD1 21 | | | | | | | S/OUTPUTS |
| CLR | PD2 22 | | | CHI | | | | |
| | P03 23 | | | | | | | IPUT |
| 1 | PD4 24 | | | | | | | INPUT |
| | PD5 27 | A0~ | | | | | | |
| | PO6 28 | | | RES | | | | |
| | P07 29 | С | LR; | CLE | AR | INPU | Ť | |
| L | | PAO-F | A7; | POR | ТΑ | INP | UTS/ | OUTPUTS |
| | | PBO-P | 87; | POR | ТВ | INP | UTS | OUTPUTS |
| | | PCO-P | C7 : | POR | тс | INP | UTS. | OUTPUTS |
| | | POO-P | יחד : | PUB | ТБ | INP | ITS. | OUTPUTS |
| | | | | | | | | 0011 013 |




CXK5864BM-10L (SONY) (ACCESS TIME = 100nS) FLAT PACKAGE C-MOS 64K(8192x8)-BIT STATIC RAM







HD64180ZF (HITACHI) FLAT PACKAGE C-MOS 8-BIT MICROPROCESSOR



| PiN NO. | 1/0 | SYMBOL | PIN NO. | 1/0 | SYMBOL | PIN NO. | | SYMBOL | PIN NO. | 1/0 | SYMBOL |
|------------|-----|--------|------------|-----|----------|------------|-----|------------|------------|------|--------|
| 1 | l l | NM1 | 21 | 0 | A11 | 41 | 1/0 | D6 | 61 | 0 | HALT |
| 2 | _ | NC | 22 | - | NC | 42 | - | NC | 62 | mar. | NC |
| 3 | - | NC | 23 | - | NC | 43 | - | i NC | 63 | - | NC |
| 4 | 1 | INTO | 24 | 0 | A12 | 44 | 1/0 | D7 | 64 | 0 | REF |
| 5 | 1 | INT1 | 25 | 0 | A13 | 45 | 0 | PITS0 | 65 | 0 | ΙΘĖ |
| 6 | -1 | INT2 | 26 | 0 | A14 | 46 | 1 | CTSO | 66 | 0 | ME |
| 7 | 0 | ST | 27 | 0 | A15 | 47 | 1 | DCD0 | 67 | 0 | E |
| 8 | 0 | A0 | 28 | 0 | A16 | 48 | 0 | TXA0 | 68 | 0 | LIA |
| 9 | 0 | A1 | 29 | 0 | A17 | 49 | 1 | RXA0 | 69 | 0 | WR |
| 10 | 0 | A2 | 30 | - | NC | 50 | 1/0 | CKA0/DREQ0 | 70 | 0 | AD |
| 11 | 0 | A3 | 31 | 0 | A18/TOUT | 51 | - | NC | 71 | 0 | + |
| 12 | | Vss | 32 | | VCC | 52 | 0 | TXA1 | 72 | | Vss |
| 13 | 0 | A4 | 33 | 0 | A19 | 53 | | TEST | 73 | | Vss |
| 14 | _ | NC | 34 | | Vss | 54 | 1 | RXA1 | 74 | ı | XTAL |
| 15 | 0 | A5 | 35 | 1/0 | D0 | 55 | 1/0 | CKA1/TENDO | 75 | - | NC |
| 16 | 0 | A6 | 36 | 1/0 | D1 | 56 | 0 | TXS | 76 | 1 | EXTAL |
| 17 | 0 | A7 | 37 | 1/0 | D2 | 57 | 1 | AXS/CTS1 | 77 | 1 | WAIT |
| 18 | 0 | 8A | 38 | 1/0 | D3 | 58 | 1/0 | CKS | 78 | 0 | BUSACK |
| 19 | 0 | A9 | 39 | 1/0 | D4 | 59 | 1 | DREQ1 | 79 | 1 | BUSREQ |
| 20 | 0 | A10 | 40 | 1/0 | D5 | 60 | 0 | TEND1 | 80 | 1 | RESET |




76 EXTAL




MC14053BF (MOTOROLA) FLAT PACKAGE


C-MOS TRIPLE 2-CHANNEL ANALOG MULTIPLEXER/DEMULTIPLEXER - TOP VIEW -




| | CON. | r, INPUTS | ON |
|----------------|------|------------|---------|
| | EN | A (X,Y,Z,) | CHANNEL |
| O; LOW LEVEL | 0 | 0 | 0 |
| 1 ; HIGH LEVEL | 0 | 1 | 1 |
| X DON'T CARE. | 1 | × | OPEN |
| | | | |




SN74HC04NS (TI) (V $_{\infty}$ = + 2 to +6V) FLAT PACKAGE C-MOS HEX INVERTER – TOP VIEW –




SN74HC138NS (Ti) (V_{00} = + 2 to + 6V) FLAT PACKAGE C-MOS 3-TO-8 LINE DECODER/DEMULTIPLEXER - TOP VIEW -



SN74HC163NS (Ti) (V $_{00}$ = + 2 to + 6V) FLAT PACKAGE C-MOS PRESETTABLE SYNCHRONOUS 4-BIT BINARY COUNTER - TOP VIEW -







| CON | TROL | INP | UTS | MODE |
|-----|------|-----|-----|------------------------|
| Rρ | LD | EN1 | EN2 | MODE |
| ٥ | × | × | × | RESET (SYNCHRONOUS) |
| 1 | 0 | x | × | PRESET (SYNCHRONOUS |
| 1 | 1 | 0 | × | NO COUNT |
| 1 | 1 | X | 0 | NO COUNT |
| 1 | 1 | 1 | 1 | COUNT |




 SN74HC245NS (TI) (V $_{00}$ = + 2 to +6V) FLAT PACKAGE C-MOS BILATERAL BUS TRANSCEIVERS WITH 3-STATE OUTPUTS - TOP VIEW -







SN74HC32NS (TI) FLAT PACKAGE C-MOS 2-INPUT OR GATE - TOP VIEW -



SN74HC374NS (TI) (V $_{\infty}$ = + 2 to +6V) FLAT PACKAGE C-MOS 3-STATE OCTAL D-TYPE FLIP-FLOP - TOP VIEW -




SN74HC573NS (TI) ($V_{DD} = +2$ to +6V) FLAT PACKAGE C-MOS 3-STATE OUTPUTS OCTAL LATCHES




SN74HC86NS (TI) FLAT PACKAGE

C-MOS EXCLUSIVE OR GATE - TOP VIEW -



TC5068BP (TOSHIBA)

C-MOS BCD-TO-SEVEN-SEGMENT LATCH/DECODER/DRIVER - TOP VIEW -




| _ | | 4345 | 1100 | | | | | | | | | | _ | | |
|-----|-----|------|------|----|---|----|----|------|-----|-----|-----|----|------|-------------|---------|
| _ | | INF | UT | , | | | | OUTF | VT(| PEN | DRA | N) | | DISPLAY | DECIMAL |
| ST | BL | D | c | В | Α | 0 | b | С | đ | | f | 9 | ZERO | HEXADECIMAL | DECIMAL |
| x | 1 | | × | x | х | | 0 | 0 | . 0 | 0 | ID. | 0 | # | BLANK | |
| _!_ | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | | 0 |
| 1_ | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 1 | 1 |
| _! | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | t | .1 | 0 | 1 | 0 | 2 | 2 |
| _1_ | 0 | 0 | 0 | .1 | 1 | 1_ | 1 | 1 | 1 | 0 | 0 | 1 | 0 | 3 | 3 |
| 1_ | 0 | 0 | 1 | O | 0 | 0 | -1 | 1 | 0 | 0 | 1 | 1 | 0 | 4 | 4 |
| | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | . 1 | 1 | 0 | 5 | 5 |
| | 0 | 0 | 1 | 1_ | 0 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 6 | 6 |
| 1 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 7 | 7 |
| | 0 | 1 | 0 | 0 | 0 | | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 8 | 8 |
| | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 1 | . 1 | 0 | 1 | 1 | 0 | 9 | 9 |
| 1 | _0_ | | 0 | 1 | 0 | 1 | ī | 1 | 0 | 1 | . 1 | 1 | 0 | А | 10 |
| ! | 0 | | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | | 71 |
| 1 | 0 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 1 1 | 1 | 1 | 0 | 0 | C | 12 |
| 1 | _0_ | _1 | _1_ | ٥ | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | d | 13 |
| 1 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 1 | 0 | Ε | 14 |
| 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | F | 15 |
| 0 | 0 | × | × | X | x | | | _ | | 4 | r | | | | |

X; DON'T CARE *; UNDETERMINED

*; DEPENS UPON THE BCD CODE PREVIOUSLY APPLIED WHEN ST="H"


TC74HC4028F (TOSHIBA) FLAT PACKAGE




| STATE | | NP | UT | S | Г | | - (| OU. | TΡ | UT | s | | _ | | |
|-------|---|----|----|---|----|----|-----|-----|----|----|----|----|----|----|---------------|
| STATE | D | C | Β | Α | YO | Υï | Y2 | Υ3 | Y4 | Y5 | Y6 | Y7 | Y8 | Υ9 | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| -1 | 0 | O | 0 | 1 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 2 | 0 | 0 | 1 | 0 | 0 | 0 | 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 3 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 4 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 4 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | |
| 5 | 0 | 4 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 4 | 0 | 0 | 0 | 0 | |
| 6 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | |
| 7 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 4 | 0 | 0 | O; LOW LEVEL |
| 8 | 1 | Х | Х | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1; HIGH LEVEL |
| 9 | 1 | X | X | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | X; DON'T CARE |


TL7700CPS (TI) FLAT PACKAGE

VARIABLE SUPPLY VOLTAGE SUPERVISOR










TMS27C256-25 (TI) (ACCESS TIME = 250nS)


C-MOS 256K(32Kx8)-BIT ERASABLE PROM WITH 3-STATE OUTPUTS — TOP VIEW — $^{\circ}$



| | A 11 | CE | UE | A hb | Un | FUNCTION - | 0 = 0 |
|---|-------------|----|-----|--------|------|----------------|--------------------------------|
| | An | 0 | 0 | + 5V | Dour | READ | ۾ ۾ ۾ |
| | An | 0 | 1 | + 5V | HI-Z | OUTPUT DISABLE | |
| | Х | 1 | X | + 5V | HI-Z | STANDBY | |
| | An | 0 | 1 - | + 21 V | DiN | PGM | 0: LOW LEVEL |
| i | An | 0 | 0 | + 21 V | Dout | PGM VERIFY | 1: HIGH LEVEL X: DON'T CARE |
| | Х | 1 | 1 | + 21 V | HI-Z | PGM INH | H-Z : HIGH IMPEDANCE |

uPD70040 (NEC)

C-MOS 10-BIT SUCCESSIVE COMPARATOR TYPE A/D CONVERTER - TOP VIEW -



AO ; CONTROL ADDRESS INPUT CHO~7; ANALOG INPUT CODE ; CODE SELECT (2'S COMPLEMENT/ BINARY) INPUT

CS ; CHIP SELECT INPUT
DBO~7; DATA BUS INPUT/OUTPUT

DEVO. DEV1; CLOCK RATE SELECT INPUT EDC ; CONVERSION ENDING SIGNAL OUTPUT


, MODE SELECT INPUT

; SERIAL CLOCK INPUT ; SERIAL CLOCK OUTPUT ; SHIFT SELECT (LSB FIRST/ SCKI SHIFT

MSB FIRST) \$1 \$0 SERIAL OUTPUT

SOFN SERIAL OUTPUT ENABLE OUTPUT ; ADDRESS WRITE STROBE SIGNAL INPUT

; WRITE SIGNAL INPUT



| MC | MODE |
|----|----------|
| 0 | SERIAL |
| 1 | PARALLEL |

| PAR | ALLE | L MO | DE | |
|-----|------|------|----|---|
| ĊS | WR | RD | AO | MODE |
| 1 | Х | Х | X | HIGH IMPEDANCE |
| 0 | . 1 | 1 | X | HIGH IMPEDANCE |
| 0 | 0 | - 4 | 0 | #1 ANALOG CHANNEL SELECT |
| 0 | 0. | 1 | 1 | *2 CODE SELECT/ *3 CLOCK RATE SELECT |
| 0 | 1 | 0 | 0 | #4 LOW-BYTE DATA OUTPUT |
| 0 | 1 | 0 | 1 | #4 HIGH-BYTE DATA OUTPUT |
| 0 | 0 | 0 | X | INHIBIT |
| | | | 0; | LOW LEVEL X : DON'T CARE |

| SEL2 | SEL 1 | SELO | MPX CHAN. |
|------|-------|------|-----------|
| 0 | 0 | 0 | СНО |
| 0 | 0 | _ 1 | CHI |
| 0 | 1 | 0 | CH 2 |
| 0 | . 1 | . 1 | CH 3 |
| 1 | 0 | 0 | CH4 |
| 1 | 0 | 1 | CH5 |
| - 1 | - 1 | 0 | CH6 |
| 1 | 1 | 1 | CH7 |

#1 ANALOG CHANNEL

*2 CODE SELECT

CODE CODE SELECT

O BINARY DATA

1 2°S COMPLEMENT DATA

| #3 CLC | CK RAT | E SELECT |
|--------|--------|------------|
| DEV1 | DEV 0 | CLOCK RATE |
| 0 | 0 | 1 |
| 0 | 1 | 1/2 |
| 1 | 0 | 1/4 |
| 1 | 1 | 1/8 |

*4 LOW/HIGH-BYTE DATA
| D87 | D86 | D85 | D84 | D83 | D82 | D81 | D80 | HIGH-BYTE MSB 2ND 3RD 4TH 5TH 6TH 7TH BTH LOW-BYTE 9TH 0 0 0 0 0 0 0

SECTION C SPARE PARTS

PARTS INFORMATION

1. Safety Related Component Warning

Components indentified by shading marked with \triangle on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony parts whose parts numbers appear as shown in this manual or in service manual supplements published by Sony.

- 2. Replace Parts that are supplied from Sony Parts Center can sometimes have different shape and external appearance than what are actually used in equipment. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts."
 - This manual 's exploded view and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present."
 - · Regarding engineering parts and diagrams changes in our engineering department, refer to Sony service bulletins and service manual supplements.
- 3. The parts marked with "S" in the SP column of the exploded views and electrical spare parts list are normally required for routine service work. Orders for parts marked with "O" will be processed, but allow for additional delivery time.
- 4. Item with no parts number and/or no description are not stocked because they are seldom required for routine service.
- 5. Regarding engineering parts changes in our engineering department, refer to SECTION D "CHANGED PARTS".

6. Abbreviation

| REF.NO. | DESCRIPTION | REF.NO. | DESCRIPTION | REF.NO. | DESCRIPTION |
|---------|--------------------|---------|-------------------|---------|-------------------|
| BT | BATTERY | F | FUSE | RB, RP | RESISTOR BLOCK |
| BZ | BUZZER | FB | FERRITE BEAD | RY | RELAY |
| С | CAPACITOR | FL | FILTER | RV | VARIABLE RESISTOR |
| CF | CERAMIC FILTER | IC | IC | S | SWITCH |
| CN | CONNECTOR | L | INDUCTOR | T | TRANSFORMER |
| CP | COMBINATION PARTS | LV | VARIABLE INDUCTOR | TH | THERMISTOR |
| cv | VARIABLE CAPACITOR | PL | PILOT LAMP | TM | TIMER |
| D | DIODE | Q | TRANSISTOR | VDR | VARISTOR |
| DL | DELAY LINE | R | RESISTOR | X | OSCILLATOR |

All capacitors are in micro farads unless otherwise specified.

All inductors are in micro henries unless otherwise specified.


All resistors are in ohms.

EXPLODED VIEW


RCP-3720/3721

```
No.
                           Part No.
                                                                          SP Description
                           A-7515-059-A o MOUNTED CIRCUIT BOARD, SW-371
A-7515-060-A o MOUNTED CIRCUIT BOARD, MPU-53
A-7612-369-A o JOY STICK ASSY (RCP-3720 ONLY)
X-2141-006-1 o PANEL ASSY (D2), CONTROL
(RCP-3721 ONLY)
X-2270-601-O s KNOB ASSY (RCP-3721 ONLY)
                                                                                                                                                                                                                                                                                      -356-549-01 o COVER (2). LED (RCP-3721 ONLY)
-356-558-01 o TUBE. FIXED, VR (RCP-3720 ONLY)
-356-559-01 o TUBE. ADJUSTMENT (RCP-3720 ONLY)
-356-560-01 o TUBE, COVER (RCP-3720 ONLY)
-356-561-01 o SHAFT, FIXED, COVER (RCP-3720 ONLY)
                                                                                                                                                                                                                                                     48
49
50
    5
                                                                                                                                                                                                                                                                                      -356-571-01 o ESCUTCHEON, LEVER (RCP-3720 ONLY)
-306-006-00 s CUSHION, MOTOR (RCP-3720 ONLY)
-657-810-00 s BEARING (LF1280ZZ), BALL
(RCP-3720 ONLY)
                          X-2355-502-1 s KNOB ASSY, CONTROL
X-3651-342-0 s KNOB ASSY, CONTROL (RCP-3721 ONLY)
1-224-981-00 s RES, VAR, CERMET 5K "IRIS"
(RCP-3721 ONLY)
1-224-981-31 s RES, VAR, CERMET 5K
"MASTER BLACK" (RCP-3720 ONLY)
1-230-138-00 s RES, VAR, CARBON 5K "BLACK" "WHITE"
    8
                                                                                                                                                                                                                                                                                  3-657-864-00 o SUPPORT, DP
3-672-251-00 s RING (M4), O (RCP-3720 ONLY)
    9
                                                                                                                                                                                                                                                                                3-692-963-01 s WASHER (A) (RCP-3720 ONLY)
3-701-444-21 s WASHER, 6 (RCP-3720 ONLY)
3-701-510-00 s SET SCREW, DOUBLE POINT 4X4
(RCP-3720 ONLY)
3-712-653-01 s NUT (M8), TUBE (RCP-3720 ONLY)
4-812-554-00 s WASHER (RCP-37220 ONLY)
10
                          1-230-817-11 s RES, VAR, CARBON 5K "IRIS" (RCP-3720 ONLY)
1-237-955-11 s RES, VAR, CARBON 10K "SENS"
1-238-293-11 s RES, VAR, CARBON 10K "KNEE"
"GAMMA" "DETAIL" "COARSE"
1-561-795-00 s SOCKET, CONNECTOR 6P "PREVIEW"
1-564-968-11 s CONNECTOR, MULTI (SQUARE) 16P "CCU"
                                                                                                                                                                                                                                                      58
11
12
13
                                                                                                                                                                                                                                                                                4-870-261-00 o SUPPORT (RCP-3720 ONLY)
4-876-607-21 o COLLAR (E), PLATE, LACK
1-224-981-41 s RES, VER, CERMET 5K
"MASTER BLACK" (RCP-3721 ONLY)
                          1-570-504-11 s SWITCH, MICRO "LOCK" (RCP-3720 ONLY)
1-632-786-11 o PRINTED CIRCUIT BOARD, LED-98
1-632-787-11 o PRINTED CIRCUIT BOARD, IR-12
(RCP-3720 ONLY)
1-632-788-11 o PRINTED CIRCUIT BOARD, DSP-27
(RCP-3720 ONLY)
1-632-789-11 o PRINTED CIRCUIT BOARD, DSP-28
(RCP-3721 ONLY)
18
19
20
                           2-141-002-01 o LABEL, FUNCTION
2-141-006-01 o GUARD (SQUARE 6), SWITCH
2-141-013-01 o GEAR (A), IRIS (RCP-3720 ONLY)
2-141-014-01 o GEAR (B), IRIS (RCP-3720 ONLY)
2-141-015-01 o PLATE, COLOR
                           2-141-015-11 o PLATE, COLOR
2-141-015-21 o PLATE, COLOR
2-141-017-01 s KNOB, RV
2-141-027-01 o CHASSIS (D2), SUB (RCP-3721 ONLY)
2-141-028-01 o PLATE (2), FIXED, RV
                           2-141-029-01 o BRACKET (2), RACK
2-141-030-01 o COVER (J2), LED (RCP-3720 ONLY)
2-141-031-01 o INSULATOR (2)
2-141-032-01 o COVER (SHUTTER), LED
2-141-033-01 o COVER (FILTER), LED
                           2-141-036-01 o PANEL (J2), CONTROL (RCP-3720 ONLY)
2-141-037-01 o CHASSIS (B2), SUB
2-141-038-01 o CHASSIS (J2), SUB (RCP-3720 ONLY)
2-141-039-01 o COVER (S)
2-141-040-01 o PANEL (B2), CONTROL
36
37
38
39
                           2-141-041-01 o COVER (B2)
2-249-395-02 o NUT, PLATE, 4P
2-280-622-41 o SUPPORT (M3), HEXAGON
2-356-547-01 o TUBE, LEVER FIXED (RCP-3720 ONLY)
2-356-548-01 o COVER (1), LED (RCP-3721 ONLY)
```

EXPLODED VIEW





SCREWS




| +B Cr-N | | |
|---------------|------------------|--|
| | | |
| 7-682-000-00- | | |
| SIZE | Parts No. | |
| 3 x 3 | 144-01 | |
| × 4 | 145-01 | |
| x 5 | 146-01 | |
| x 6 | 147-01 | |
| x 8 | 148-01 | |
| x 10 | 149-01 | |
| x 12 | 150-01 | |
| x 14 | 151-01 | |
| x 16 | 152-01 | |
| x 20 | 153-01 | |
| 4 x 4 | 158-01 | |
| x 5 | 159-01 | |
| x 6 | 160-01 | |
| x 8 | 161-01 | |
| × 10 | 162-01 | |
| x 12 | 163-01 | |
| x 14 | 164-01 | |
| × 16 × 20 | 165-01 166-01 | |
| x 20 | 100-01 | |
| 5 x 8 | 174-01 | |
| x 10 | 175-01 | |
| x 12 | 176-01 | |
| x 14 | 177-01 | |
| × 16 | 178-01 | |
| x 20 | 179-01 | |

| +PSW Czn-N | | |
|---------------|----------------------------|--|
| | | |
| 7-682-000-00 | | |
| SIZE | Parts No. | |
| 3 x 6 | 947-01 | |
| x 8 | 948-01 | |
| x 10 | 949-01 | |
| x 12 | 950-01 | |
| 'x 14 | 951-01 | |
| x 16 | 951-01 952-01 953-01 | |
| × 20 | | |
| × 25 × 30 | 954-01 955-01 | |
| x 30 x 35 | 955-01 | |
| x 40 | 957-01 | |
| 4 × 8 | 961-01 | |
| x 10 | 962-01 | |
| x 12 | 963-01 | |
| к 14 | 964-01 | |
| х 16 | 965-01 | |
| x 20 | 966-01 | |
| x 25 | 967-01 | |
| x 30 | 968-01 | |
| × 35 × 40 | 969-01 970-01 | |







| TOTSU P BZn-N NON SLIT | | |
|---------------------------|------------------|--|
| | | |
| 7-685-000-00 | | |
| SIZE | Perts No. | |
| 2 × 4 | 102-19 | |
| 2 x 5 | 103-19 | |
| 2 × 6 | 104-19 | |
| 2 x 8 2 x 10 | 105-19 106-19 | |
| 2 x 12 | 107-19 | |
| 2.6 x 4 | 131-19 | |
| 2.6 x 5 | 132-19 | |
| 2.6 x 6 2.6 x 8 | 133-19 134-19 | |
| 2.6 x 10 | 135-19 | |
| 2.6 x 12 | 136-19 | |
| 2.6 x 14 | 137-19 | |
| 2.6 × 16 | 138-19 | |
| | | |
| 3 × 5 | 144-19 | |
| 3 x 6 3 x 8 | 145-19 146-19 | |
| 3 x 6 | 147-19 | |
| 3 x 12 | 148-19 | |
| 3 x 14 | 149-19 | |
| 3 x 16 | 150-19 | |
| 3 × 18 | 1 | |
| 3 x 20 3 x 25 | 151-19 | |
| 3 x 25 3 x 30 | 152-19 153-19 | |
| 3 x 30 3 x 35 | 153-19 | |
| 3 × 40 | 155-19 | |
| 3 x 58 | | |
| 4 × 6 | 158-19 | |
| 4 x 8 | 159-19 | |
| 4 × 10 | 160-19 | |
| 4 x 12 4 x 14 | 161-19 | |
| 4 × 14 4 × 16 | 162-19 163-19 | |
| 4 × 20 | 164-19 | |
| 4 x 25 | 165-19 | |
| 4 x 30 | 166-19 | |
| 4 x 35 | 167-19 | |

| DSP-27 BC | DARD "RCP-3720 ONLY" | MPU-53 BG | OARD |
|--|--|---------------------------------|---|
| Ref. No. | Part No. SP Description | Ref. No. | Part No. SP Description |
| 4pcs | 1-563-521-11 o CONNECTOR, 20P, FEMALE 1-632-788-11 o PRINTED CIRCUIT BOARD, DSP-27 | 1pc | A-7515-060-A o MOUNTED CIRCUIT BOARD, "MPU-53" |
| CN1 CN2 CN3 | 1-566-405-11 o CONNECTOR, 30P, MALE 1-506-471-11 o CONNECTOR, 6P, MALE 1-506-469-11 o CONNECTOR, 4P, MALE | C1 C2 C3 C4 C5 | 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V |
| D1 D2 D3 | 8-719-939-53 s DIODE LB-203ML 8-719-948-06 s DIODE LB-202ML 8-719-938-68 s GL-3HY8 | C6 C7 C8 C9 | 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V |
| S1 S2 | 1-554-048-00 s SWITCH, PUSH 1-554-048-00 s SWITCH, PUSH | C10 | 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V |
| gare hape spale dide dide dall did gas | | C11 C12 C13 C14 C15 | 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V |
| DSP-28 B Ref. No. | OARD "RCP-3721 ONLY" | C16 C17 | 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V |
| or Q'ty | Part No. SP Description | Č18 C19 C20 | 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V 1-163-129-00 s CERAMIC CHIP 330PF 5% 50V 1-163-097-00 s CERAMIC CHIP 15PF 5% 50V 1-163-097-00 s CERAMIC CHIP 15PF 5% 50V |
| 4pcs lpc lpc | 1-563-521-11 o CONNECTOR, 20P, FEMALE 1-632-789-11 o PRINTED CIRCUIT BOARD, "DSP-28" 2-141-017-01 s KNOB, RV 7-621-734-09 s SET-SCT, HEX. 2.6X3 | C21 | 1-131-345-00 s TANTALUM 0.47uF 10% 35V |
| lpc CN1 | 1-566-405-11 o CONNECTOR, 30P, MALE | C22 C23 C24 C25 | 1-124-484-11 s ELECT 220uF 20% 35V 1-124-472-11 s ELECT 470uF 20% 10V 1-124-472-11 s ELECT 470uF 20% 10V 1-127-515-11 s ELECT(SOLID) 47uF 20% 10V |
| CN1 CN2 D1 | 1-506-469-11 o CONNECTOR, 4P, MALE 8-719-939-53 s DIODE LB-203ML | | 1-127-515-11 s ELECT(SOLID) 47uF 20% 10V 1-163-038-00 s CERAMIC CHIP 0.1uF 25V |
| D2 D3 | 8-719-948-06 s DIODE LB-202ML 8-719-938-68 s GL-3HY8 | C26 C27 C28 C29 C30 | 1-131-347-00 s TANTALUM 1MF 10% 35V 1-163-038-00 s CERAMIC CHIP 0.1uF 25V |
| RV1 RV2 | 1-238-293-11 s RES, VAR, CARBON 10K 1-237-955-11 s CARBON 10K | | 1-126-176-11 s ELECT 220MF 20% 10V 1-163-038-00 s CERAMIC CHIP 0.1uF 25V |
| S1 | 1-554-048-00 s SWITCH, PUSH 1-554-048-00 s SWITCH, PUSH 1-554-041-11 s SWITCH, PUSH | C31 C32 C33 C34 C35 | 1-164-232-11 s CERAMIC CHIP 0.01MF 10% 100V 1-131-381-00 s TANTALUM 47uF 20% 10V 1-131-381-00 s TANTALUM 47uF 20% 10V 1-131-381-00 s TANTALUM 47uF 20% 10V 1-131-381-11 s TANTALUM 47uF 2% 10V |
| ID 10 DO | MADD. | CN1 CN2 CN3 CN4 | 1-566-400-21 o PIN, CONNECTOR 20P 1-566-401-11 o CONNECTOR, 22P, MALE 1-566-398-21 o CONNECTOR, 16P, MALE 1-506-473-11 o CONNECTOR, 8P, MALE |
| IR-12 BO Ref. No. | | D1 D2 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |
| lpc | Part No. SP Description 1-632-787-11 o PRINTED CIRCUIT BOARD, "IR-12" 2-141-017-01 s KNOB, RV | D3 D4 D5 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |
| lpc lpc | | D6 D7 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |
| RV1 RV2 | | D8 D9 D10 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |
| | | D11 D12 D13 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |
| | | D14 D15 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |
| | | D16 D17 D18 | 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 8-719-800-76 s DIODE 1SS226 |

(MPU-53 BOARD)

| (41,0-22 | DUAN()) | (111.0-22 | DUAND) |
|---------------------------------|--|---------------------|--|
| Ref. No. or Q ty | Part No. SP Description | Ref. No. or Q'ty | Part No. SP Description |
| D18 | 8-719-106-70 s DIODE RD12M-B1 | R26 | 1-216-025-00 s METAL CHIP 100 5% 1/10W |
| FB1 | 1-535-178-00 s RES, FERRITE | R27 R28 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| ICI | 8-759-925-74 s IC SN74HCO4NS | R29 R30 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-025-00 s METAL CHIP 100 5% 1/10W |
| ICŽ IC3 | 8-759-918-65 s IC TL7700CPS 8-759-008-48 s IC MC74HC86F | R31 R32 | 1-216-025-00 s METAL CHIP 100 5% 1/10W |
| IC4 IC5 | 8-759-971-23 s IC MSM80C49-757GS-K 8-759-925-85 s IC SN74HC32NS | R33 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-025-00 s METAL CHIP 100 5% 1/10W |
| | 8-759-926-67 s IC SN74HC374NS | R34 R35 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-025-00 s METAL CHIP 100 5% 1/10W |
| IC6 IC7 IC8 | 8-759-926-49 s IC SN74HC245NS 8-759-926-23 s IC SN74HC163NS | | |
| ĬĈ9 ĬĈ10 | 8-759-321-84 s HD641807F8 8-759-926-11 s IC SN74HC138NS | R36 R37 R38 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| IC11 | | R39 R40 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| ĬČĺŽ IC13 | 8-752-328-19 s IC CXK5864BM-10L 8-759-198-89 s IC 27C256A-RCP372-3.00 8-759-106-58 s IC UPD7004C | R41 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| ĬČ14 IC15 | 8-759-009-07 s IC MC14053BF 8-759-009-07 s IC MC14053BF | R42 R43 | 1-916-085-00 & METAI CHIP 33K 5% 1/10W |
| IC16 | 8-759-938-68 s IC CXD1095Q | R44 R45 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| IC17 IC18 | 8-759-234-67 s IC TMP82C79M-2 1-466-254-11 s CONVERTER UNIT, DC-DC | R46 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| JR1 | 1-216-295-00 s METAL CHIP 0 5% 1/10W | R47 R48 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| Ll | 1-410-948-11 s INDUCTOR 100uH | R49 R50 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| PH1 | 8-719-820-86 s DIODE TLP112 | | |
| | 8-729-271-23 s TRANSISTOR 2SC2712 | R51 R52 R53 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-057-00 s METAL CHIP 2.2K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| 02 02 | 8-729-216-22 s TRANSISTOR 2SA1162 8-729-216-22 s TRANSISTOR 2SA1162 | R54 R55 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| Q1 Q2 Q3 Q4 Q5 | 8-729-271-23 s TRANSISTOR 2SC2712 8-729-271-23 s TRANSISTOR 2SC2712 | | |
| - | | R56 R57 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| Q6 Q7 | 8-729-271-23 s TRANSISTOR 2SC2712 8-729-140-97 s TRANSISTOR 2SB734-34 | R58 R59 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| R1 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-121-00 s METAL CHIP 1M 5% 1/10W | R60 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W |
| R2 R3 R4 R5 | 1-216-121-00 s metal chip in 5% 1/10W 1-216-057-00 s metal chip 2.2K 5% 1/10W 1-216-085-00 s metal chip 33K 5% 1/10W | R61 R62 | 1-216-089-00 s METAL CHIP 47K 5% 1/10W 1-216-097-00 s METAL CHIP 100K 5% 1/10W 1-216-105-00 s METAL CHIP 220K 5% 1/10W |
| R5 | 1-216-085-00 s METAL CHIP 33% 5% 1/10W 1-216-079-00 s METAL CHIP 18K 5% 1/10W | R63 R64 | 1-216-067-00 s CARBON 5.6K 5% 1/10W |
| R6 R7 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W | R65 | 1-216-067-00 s CARBON 5.6K 5% 1/10W |
| R8 | 1-216-083-00 s METAL CHIP 75 5% 1/10W 1-216-022-00 s METAL CHIP 75 5% 1/10W | S1 S2 | 1-571-967-11 s SWITCH, DIP (PIANO TYPE) 1-571-967-11 s SWITCH, DIP (PIANO TYPE) |
| R9 R10 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-022-00 s METAL CHIP 75 5% 1/10W 1-216-022-00 s METAL CHIP 75 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W | X1 | 1-527-941-00 s VIBRATOR, CRYSTAL 10.944MHz |
| R11 | | | |
| R12 R13 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W | | |
| R14 R15 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W | | |
| R16 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W | | |
| R17 R18 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W | | |
| R19 R20 | 1-216-085-00 s METAL CHIP 33K 5% 1/10W 1-216-085-00 s METAL CHIP 33K 5% 1/10W | | |
| R21 | 1-216-025-00 s METAL CHIP 100 5% 1/10W | | |
| R21 R22 R23 R24 R25 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-025-00 s METAL CHIP 100 5% 1/10W | | |
| R25 | 1-216-025-00 s METAL CHIP 100 5% 1/10W 1-216-025-00 s METAL CHIP 100 5% 1/10W | | |
| | | | |

| S₩-371 BOARD | (SW-371 BOARD) |
|---|--|
| Ref. No. or Q'ty Part No. SP Description | Ref. No. or Q'ty Part No. SP Description |
| lpc A-7515-059-A o MOUNTED CIRCUIT BOARD, "SW-371" 4pcs 1-563-521-11 o CONNECTOR, 20P, FEMALE 4pcs 1-566-475-11 o PIN, SOCKET 3P 3pcs 2-141-017-01 s KNOB, RV 1pc 2-141-028-01 o PLATE (2), FIXED, RV | IC6 8-759-926-80 s IC SN74HC573NS IC7 8-759-926-80 s IC SN74HC573NS IC8 8-759-208-62 s TC5068BP IC9 8-759-208-62 s TC5068BP IC10 8-759-926-11 s IC SN74HC138NS |
| 2pcs 4-876-607-21 o COLLAR (E), PLATE, JACK 3pcs 7-621-734-09 s SET-SCT, HEX. 2.6X3 4pcs 7-682-546-04 s SCREW +B 3X5 | IC11 8-759-207-31 s IC TC74HC4028F IC12 8-759-031-84 s IC SC7S04F |
| C1 | L1 1-408-417-00 s INDUCTOR 47uH L2 1-408-417-00 s INDUCTOR 47uH L3 1-408-417-00 s INDUCTOR 47uH |
| | Q1 8-729-920-34 s TRANSISTOR DTC143XK Q2 8-729-920-34 s TRANSISTOR DTC143XK Q3 8-729-920-34 s TRANSISTOR DTC143XK Q4 8-729-920-34 s TRANSISTOR DTC143XK Q5 8-729-920-34 s TRANSISTOR DTC143XK |
| C6 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V C7 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V C8 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V C9 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V C10 1-164-232-11 s CERAMIC CHIP 0.01uF 20% 100V | Q5 8-729-920-34 s TRANSISTOR DTC143XK Q6 8-729-920-34 s TRANSISTOR DTC143XK Q7 8-729-920-34 s TRANSISTOR DTC143XK |
| C11 | 08 8-729-920-34 s TRANSISTOR DTC143XK 09 8-729-920-34 s TRANSISTOR DTC143XK 010 8-729-920-34 s TRANSISTOR DTC143XK |
| C14 1-126-157-11 s ELECT 10uF 20% 16V CN1 1-566-400-11 o CONNECTOR, 20P. MALE CN2 1-566-401-11 o CONNECTOR, 22P. MALE CN3 1-566-398-11 o CONNECTOR, 16P. MALE | Q11 8-729-920-34 s TRANSISTOR DTC143XK Q12 8-729-920-34 s TRANSISTOR DTC143XK Q13 8-729-920-34 s TRANSISTOR DTC143XK Q14 8-729-920-34 s TRANSISTOR DTC143XK Q15 8-729-920-34 s TRANSISTOR DTC143XK |
| CN4 1-566-405-11 o CONNECTOR, 30P, MALE CN5 1-506-469-11 o CONNECTOR, 4P, MALE | 016 8-729-920-34 s TRANSISTOR DTC143XK 017 8-729-920-34 s TRANSISTOR DTC143XK |
| CN6 1-566-402-11 o CONNECTOR, 24P, MALE D1 8-719-104-31 s DIODE 1S2838 D2 8-719-104-31 s DIODE 1S2838 D3 8-719-104-31 s DIODE 1S2838 | Q18 8-729-920-34 s TRANSISTOR DTC143XK Q19 8-729-920-34 s TRANSISTOR DTC143XK Q20 8-729-920-34 s TRANSISTOR DTC143XK |
| D3 8-719-104-31 s DIODE 152838 D4 8-719-104-31 s DIODE 152838 D5 8-719-104-31 s DIODE 152838 | Q21 8-729-920-34 s TRANSISTOR DTC143XK Q22 8-729-920-34 s TRANSISTOR DTC143XK Q23 8-729-920-34 s TRANSISTOR DTC143XK Q24 8-729-920-34 s TRANSISTOR DTC143XK |
| D6 8-719-104-31 s DIODE 1S2838 D7 8-719-104-31 s DIODE 1S2838 D8 8-719-104-31 s DIODE 1S2838 | Q25 8-729-920-34 s TRANSISTOR DTC143XK |
| D9 8-719-104-31 s D10DE 152838 D10 8-719-104-31 s D10DE 152838 D11 8-719-104-31 s D10DE 152838 | Q27 8-729-920-34 s TRANSISTOR DTC143XK Q28 8-729-920-34 s TRANSISTOR DTC143XK Q29 8-729-920-34 s TRANSISTOR DTC143XK Q30 8-729-920-34 s TRANSISTOR DTC143XK |
| D11 8-719-104-31 s DIODE 1S2838 D12 8-719-104-31 s DIODE 1S2838 D13 8-719-104-31 s DIODE 1S2838 D14 8-719-104-31 s DIODE 1S2838 D15 8-719-104-31 s DIODE 1S2838 | Q31 8-729-920-34 s TRANSISTOR DTC143XK Q32 8-729-920-34 s TRANSISTOR DTC143XK Q33 8-729-920-34 s TRANSISTOR DTC143XK Q34 8-729-920-34 s TRANSISTOR DTC143XK |
| D16 8-719-104-31 s DIODE 1S2838 D17 8-719-104-31 s DIODE 1S2838 D18 8-719-104-31 s DIODE 1S2838 D19 8-719-104-31 s DIODE 1S2838 | Q35 8-729-920-34 s TRANSISTOR DTC143XK Q36 8-729-920-34 s TRANSISTOR DTC143XK Q37 8-729-920-34 s TRANSISTOR DTC143XK |
| D2O 8-719-948-07 s LED LD-001MG, GRN | Q38 8-729-920-34 s TRANSISTOR DTC143XK Q39 8-729-920-34 s TRANSISTOR DTC143XK Q40 8-729-920-34 s TRANSISTOR DTC143XK |
| D21 8-719-948-06 s DIODE LB-202ML D22 8-719-948-06 s DIODE LB-202ML D23 8-719-939-52 s DIODE LA-301ML D24 8-719-939-52 s DIODE LA-301ML D25 8-719-800-76 s DIODE 1SS226 | Q41 8-729-920-34 s TRANSISTOR DTC143XK Q42 8-729-920-34 s TRANSISTOR DTC143XK Q43 8-729-920-34 s TRANSISTOR DTC143XK Q44 8-729-920-34 s TRANSISTOR DTC143XK |
| IC1 8-759-926-80 s IC SN74HC573NS IC2 8-759-926-80 s IC SN74HC573NS IC3 8-759-926-80 s IC SN74HC573NS | Q45 8-729-920-34 s TRANSISTOR DTC143XK Q46 8-729-271-23 s TRANSISTOR 2SC2712 |
| 1C4 8-759-926-80 s 1C SN74HC573NS 1C5 8-759-926-80 s 1C SN74HC573NS | 047 8-729-271-23 s TRANSISTOR 2SC2712 048 8-729-271-23 s TRANSISTOR 2SC2712 |

| Ref. No. or Q'ty Part No. SP Description | Ref. No. or Q'ty Part No. SP Description |
|---|---|
| Q49 8-729-271-23 s TRANSISTOR 2SC2712 Q50 8-729-271-23 s TRANSISTOR 2SC2712 Q51 8-729-271-23 s TRANSISTOR 2SC2712 Q52 8-729-271-23 s TRANSISTOR 2SC2712 Q53 8-729-271-23 s TRANSISTOR 2SC2712 | R31 1-216-029-00 s METAL CHIP 150 5% 1/10W R32 1-216-029-00 s METAL CHIP 150 5% 1/10W R33 1-216-029-00 s METAL CHIP 150 5% 1/10W R34 1-216-029-00 s METAL CHIP 150 5% 1/10W R35 1-216-029-00 s METAL CHIP 150 5% 1/10W |
| Q54 8-729-271-23 s TRANSISTOR 2SC2712 Q55 8-729-271-23 s TRANSISTOR 2SC2712 Q56 8-729-271-23 s TRANSISTOR 2SC2712 Q57 8-729-271-23 s TRANSISTOR 2SC2712 Q58 8-729-271-23 s TRANSISTOR 2SC2712 | R36 1-216-029-00 s METAL CHIP 150 5% 1/10W R37 1-216-025-00 s METAL CHIP 100 5% 1/10W R39 1-216-025-00 s METAL CHIP 100 5% 1/10W R40 1-216-025-00 s METAL CHIP 100 5% 1/10W R40 |
| Q59 8-729-271-23 s TRANSISTOR 2SC2712 Q60 8-729-906-45 s TRANSISTOR DTA143XK Q61 8-729-906-45 s TRANSISTOR DTA143XK Q62 8-729-906-45 s TRANSISTOR DTA143XK Q63 8-729-906-45 s TRANSISTOR DTA143XK | R41 1-216-025-00 s METAL CHIP 100 5% 1/10W R42 1-216-025-00 s METAL CHIP 100 5% 1/10W R43 1-216-025-00 s METAL CHIP 100 5% 1/10W R44 1-216-025-00 s METAL CHIP 100 5% 1/10W R45 1-216-025-00 s METAL CHIP 100 5% 1/10W |
| Q64 8-729-906-45 s TRANSISTOR DTA143XK Q65 8-729-906-45 s TRANSISTOR DTA143XK Q66 8-729-906-45 s TRANSISTOR DTA143XK Q67 8-729-906-45 s TRANSISTOR DTA143XK Q68 8-729-159-64 s TRANSISTOR 2SD596 | R46 1-216-047-00 s METAL CHIP 820 5% 1/10W R47 1-216-047-00 s METAL CHIP 820 5% 1/10W R48 1-216-047-00 s METAL CHIP 820 5% 1/10W R50 1-216-047-00 s METAL CHIP 820 5% 1/10W R50 1-216-047-00 s METAL CHIP 820 5% 1/10W |
| Q69 8-729-159-64 s TRANSISTOR 2SD596 Q70 8-729-159-64 s TRANSISTOR 2SD596 Q71 8-729-159-64 s TRANSISTOR 2SD596 Q72 8-729-159-64 s TRANSISTOR 2SD596 Q73 8-729-159-64 s TRANSISTOR 2SD596 | R51 1-216-047-00 s METAL CHIP 820 5% 1/10W R52 1-216-047-00 s METAL CHIP 820 5% 1/10W R53 1-216-047-00 s METAL CHIP 820 5% 1/10W R55 1-216-047-00 s METAL CHIP 820 5% 1/10W R55 |
| Q74 8-729-159-64 s TRANSISTOR 2SD596 Q75 8-729-159-64 s TRANSISTOR 2SD596 Q76 8-729-159-64 s TRANSISTOR 2SD596 Q77 8-729-920-34 s TRANSISTOR DTC143XK | R56 1-216-047-00 s METAL CHIP 820 5% 1/10W R57 1-216-047-00 s METAL CHIP 820 5% 1/10W R58 1-216-047-00 s METAL CHIP 820 5% 1/10W R59 1-216-047-00 s METAL CHIP 820 5% 1/10W R60 1-216-019-00 s METAL CHIP 56 5% 1/10W |
| R1 | R61 1-216-019-00 s METAL CHIP 56 5% 1/10W R62 1-216-019-00 s METAL CHIP 56 5% 1/10W R63 1-216-019-00 s METAL CHIP 56 5% 1/10W R64 1-216-019-00 s METAL CHIP 56 5% 1/10W R65 1-216-019-00 s METAL CHIP 56 5% 1/10W R65 |
| R6 1-216-029-00 s METAL CHIP 150 5% 1/10W R7 1-216-017-00 s METAL CHIP 47 5% 1/10W R8 1-216-023-00 s METAL CHIP 82 5% 1/10W R9 1-216-039-00 s METAL CHIP 390 5% 1/10W R10 1-216-039-00 s METAL CHIP 390 5% 1/10W | R66 1-216-019-00 s METAL CHIP 56 5% 1/10W R67 1-216-019-00 s METAL CHIP 56 5% 1/10W R68 1-216-049-00 s METAL CHIP 1K 5% 1/10W R69 1-216-049-00 s METAL CHIP 1K 5% 1/10W R70 1-216-049-00 s METAL CHIP 1K 5% 1/10W |
| R11 1-216-039-00 s METAL CHIP 390 5% 1/10W R12 1-216-039-00 s METAL CHIP 390 5% 1/10W R13 1-216-039-00 s METAL CHIP 390 5% 1/10W R14 1-216-039-00 s METAL CHIP 390 5% 1/10W R15 1-216-029-00 s METAL CHIP 150 5% 1/10W | R71 |
| R16 1-216-029-00 s METAL CHIP 150 5% 1/10W R17 1-216-029-00 s METAL CHIP 150 5% 1/10W R18 1-216-029-00 s METAL CHIP 150 5% 1/10W R19 1-216-029-00 s METAL CHIP 150 5% 1/10W R20 1-216-029-00 s METAL CHIP 150 5% 1/10W | R76 |
| R21 1-216-029-00 s METAL CHIP 150 5% 1/10W R22 1-216-029-00 s METAL CHIP 150 5% 1/10W R23 1-216-029-00 s METAL CHIP 150 5% 1/10W R24 1-216-029-00 s METAL CHIP 150 5% 1/10W R25 1-216-053-00 s METAL CHIP 1.5K 5% 1/10W | R81 |
| R26 1-216-053-00 s METAL CHIP 1.5K 5% 1/10W R27 1-216-053-00 s METAL CHIP 1.5K 5% 1/10W R28 1-216-029-00 s METAL CHIP 150 5% 1/10W R29 1-216-029-00 s METAL CHIP 150 5% 1/10W R30 1-216-029-00 s METAL CHIP 150 5% 1/10W | RV1 1-230-138-00 s RES, VAR, CARBON 5K RV2 1-230-138-00 s RES, VAR, CARBON 5K RV3 1-230-138-00 s RES, VAR, CARBON 5K RV4 1-230-138-00 s RES, VAR, CARBON 5K RV5 1-230-138-00 s RES, VAR, CARBON 5K |

| (SW-371 BOARD) | FRAME |
|--|--|
| Ref. No. or Q'ty Part No. SP Description | Ref. No. or Q'ty Part No. SP Description |
| RV6 1-230-138-00 s RES, VAR, CARBON 5K RV7 1-238-293-11 s RES, VAR, CARBON 10K RV8 1-238-293-11 s RES, VAR, CARBON 10K RV9 1-238-293-11 s RES, VAR, CARBON 10K | 1-224-981-31 s RES, VAR, METAL 5K "MASTER BLACK" (FOR RCP-3720) 1-224-981-41 s RES, VAR, METAL 5K "MASTER BLACK" (FOR RCP-3721) |
| \$1 | 1-230-817-11 s RES, VAR, METAL 5K "IRIS" (FOR RCP-3720) 1-224-981-00 s RES, VAR, METAL 5K "IRIS" (FOR RCP-3721) |
| \$6 | 1-570-504-11 s SWITCH, MICRO "LOCK" (FOR RCP-3720) CN1F (to DSP-27 board) (FOR RCP-3720) 1-563-883-11 o HOUSING, 30P 1-563-869-11 o CONTACT, FEMALE AWG26-30 |
| \$11 | CN1F (to DSP-28 board) (FOR RCP-3721) 1-563-883-11 o HOUSING, 30P 1-563-869-11 o CONTACT, FEMALE AWG26-30 |
| \$16 | CN1F (to MPU-53 board) 1-563-878-11 o HOUSING, 20P 1-563-869-11 o CONTACT, FEMALE AWG26-30 |
| \$20 1-570-207-91 s SWITCH, PUSH \$21 1-570-207-71 s SWITCH, PUSH \$22 1-570-208-11 s SWITCH, PUSH \$23 1-570-209-11 s SWITCH, PUSH \$24 1-570-209-11 s SWITCH, PUSH | CN1F (to SW-371 board) 1-563-878-11 o HOUSING, 20P 1-563-869-11 o CONTACT, FEMALE AWG26-30 CN2F (to DSP-27 board) (FOR RCP-3720) |
| \$25 1-570-209-11 s SWITCH, PUSH \$26 1-554-048-00 s SWITCH, PUSH \$27 1-570-207-61 s SWITCH, PUSH \$28 1-554-048-00 s SWITCH, PUSH \$29 1-570-207-51 s SWITCH, PUSH \$30 1-570-207-31 s SWITCH, PUSH | 1-562-151-11 o HOUSING, 6P 1-563-088-11 o CONTACT, FEMALE AWG24-30 CN2F (to DSP-28 board) (FOR RCP-3721) 1-562-149-11 o HOUSING, 4P 1-563-088-11 o CONTACT, FEMALE AWG24-30 |
| S31 1-570-207-21 s SWITCH, PUSH S32 1-570-207-11 s SWITCH, PUSH | CN2F (to MPU-53 board) 1-563-879-11 o HOUSING, 22P 1-563-869-11 o CONTACT, FEMALE AWG26-30 |
| | CN2F (to SW-371 board) 1-563-879-11 o HOUSING, 22P 1-563-869-11 o CONTACT, FEMALE, AWG26-30 |
| | CN3F (to MPU-53 board) 1-563-876-11 o HOUSING, 16P 1-563-869-11 o CONTACT, FEMALE, AWG26-30 |
| | CN3F (to SW-371 board) 1-563-876-11 o HOUSING, 16P 1-563-869-11 o CONTACT, FEMALE, AWG26-30 |
| | CN4F (to MPU-53 board) 1-562-153-11 o HOUSING, 8P 1-563-088-11 o CONTACT, FEMALE, AWG24-30 |
| | CN4F (to SW-371 board) 1-563-883-11 o HOUSING, 30P 1-563-869-11 o CONTACT, FEMALE, AWG26-30 |
| | CN5F (to SW-371 board) 1-562-149-11 o HOUSING, 4P 1-563-088-11 o CONTACT, FEMALE, AWG24-30 |

(FRAME)

Ref. No. or Q'ty Part No. SP Description

CN101 CN102 1-564-968-11 s CONNECTOR, 16P, FEMALE "CCU" 1-561-795-00 s SOCKET 6P, FEMALE "PREVIEW" PACKING MATERIALS & SUPPLIED ACCESSORIES

Ref. No. or Q'ty Part No. SP Description

1pc 2pcs

1-560-691-11 s PLUG 6P, MALE 1-564-970-11 s CONNECTOR, MULTI (SQUARE) 16P, FEMALE 2-141-029-01 o BRACKET (2), RACK 2-355-375-01 o PLATE, NUMBER 2pcs 1pc